



Basic Manual

GRATINA

グラティナー

Illustrations and
Screenshots
in This Manual

Safety Precautions/Notes on
waterproof, dustproof and
shock-resistant properties

Notes on Cell Phone Use

Contents

Getting Ready

Making and
Answering Calls

Global Function

Character Input

Phone Book

Mail

Camera

EZweb

EZ News Flash

EZ Navi

TV (1Seg)

In Case of
Loss of Your GRATINA

Troubleshooting

Index

Introduction

Thank you for buying the GRATINA (simply called the "product" from here on). Before using your product, be sure to read the Basic Manual (this PDF manual) to ensure correct usage. After you have finished reading this manual, store this PDF manual and the printed manuals and keep it with your care so you can retrieve them whenever you need them.

Manuals for the product

There are three manuals for the product: the Basic Manual, printed Instruction Manual (Japanese) and full Instruction Manual (Japanese).

● For learning the basics:

Read the Basic Manual (this manual) or printed Instruction Manual (Japanese).

● For learning details of each function:

The full Instruction Manual (Japanese) gives detailed instructions on using each function and can be downloaded from the au homepage: <http://www.au.kddi.com/support/mobile/guide/manual/>

The keyword searchable au Online Manual is also available on the au homepage.

- To access from EZweb (free of packet communication charge):

 ⇒ Top Menu/Search ⇒ auお客さまサポート (au Customer Support) ⇒ オンラインマニュアル (Online Manual)

Scan this QR code to access the au Online Manual. ▶




Safety Precautions

Be sure to read the Safety Precautions in this manual to ensure proper usage of the GRATINA.

Illustrations and Screenshots in This Manual

Note on Illustrations

The illustrations in this manual may look different from the actual cell phone in shape, color and typeface. The key illustrations are also simplified as shown below.



	Key Illustration		Key Illustration
①		⑦	
②		⑧	
③		⑨	
④		⑩	
⑤			
⑥	<div> <div>1あ.世</div> <div>2かABC</div> <div>3こDEF</div> <div>4にGHI</div> <div>5おJKL</div> <div>6はMNO</div> <div>7まPQRS</div> <div>8やTUV</div> <div>9らWXYZ</div> <div>＊＋α</div> <div>0わE&..</div> <div>＃コJ</div> </div>		

Note on Screenshots

The screenshots in this manual are simplified and may look different from the actual cell phone screens.

- The display design themes of the product vary by model color. The operations and the screenshots for the Orange models are used in this manual.

Safety Precautions/Notes on waterproof, dustproof and shock-resistant properties

Exemptions

- The Company is not liable for any damages arising from earthquakes, lightning, storms, floods or other natural disasters, as well as fires, actions by third parties, other accidents, intentional or mistaken misoperation by the customer, or use under other unusual conditions outside the responsibility of the Company.
- The Company is not liable for any incidental damages (change/disappearance of described content, loss of business income, disruption of business, etc.) arising from use of or inability to use the product.
- The Company is not liable for any damages arising from failure to observe the described content of the "Instruction Manual".
- The Company is not liable for any damages arising, for example, from malfunction caused by combination with connected devices or software not related to the Company.
- Captured image data or downloaded data may sometimes be altered or lost due to faults, repair or other handling of the product. The Company is not liable for any damage or lost income resulting from recovery of these data.
- It is recommended you keep a copy of important data in your PC's hard disk, etc. Whatever the cause of fault or malfunction may be, the Company assumes no responsibility for alteration or loss of saved information.

- Reproduction of the content of this manual in part or in whole is prohibited.
- The content of this manual is subject to change without notice.
- Every effort has been made in the preparation of this manual. Should you notice any unclear points, omissions, etc., feel free to contact us.




* "The Company" as appears in this manual refers to the following companies:
Sold by: KDDI CORPORATION, OKINAWA CELLULAR TELEPHONE COMPANY
Manufactured by: KYOCERA Corporation

Safety Precautions (Observe Strictly)

■ Before using this product, thoroughly read these safety precautions for proper use. After reading, store the precautions in a safe place.

- These "Safety Precautions" describe instructions that should be observed to prevent damage to property or injury to the customer or others using the product.
- These instructions are divided into the following categories.

■ Explanation of indications used in this manual







 DANGER	This symbol indicates the potential and imminent danger of death or serious injury ^{*1} to a person.
 WARNING	This symbol indicates the possibility of death or serious injury ^{*1} to a person.
 CAUTION	This symbol indicates the possibility of personal injury ^{*2} to a person or physical damage ^{*3} .

*1 Serious injury: This refers to loss of sight, injury, burns (high- and low-temperature), electric shock, broken bones, injuries with residual aftereffects from poisoning, etc., and injuries requiring hospital admission for treatment or long-term hospital attendance as an outpatient.

*2 Injury: This refers to injuries, burns (high- and low-temperature), electric shock, etc. that do not require hospital admission for treatment or long-term hospital attendance as an outpatient.

*3 Physical damage: This refers to extended damage to buildings, furniture, livestock, or pets.

■ Explanation of graphic symbols used in this manual

	Indicates an action that is not allowed.
	Indicates that handling with wet hands is not allowed.
	Indicates that disassembly is not allowed.
	Indicates that use in a place where the product is likely to get wet or allowing the product to get wet is not allowed.
	Indicates an action that must be done.
	Indicates that the power plug must be disconnected from the power outlet.

Precautions common to the main unit, battery pack, back cover, charging equipment, micro au IC-Card 02, peripheral devices

⚠ DANGER Be sure to read the following hazards before use.



Be sure to use only the specified peripheral devices. Use of other peripheral devices might cause overheating, fire, rupture, fault, or leakage of liquid.



Do not use, store or leave the product in hot places (e.g. by the fire, near a heater, under a kotatsu, in direct sunlight, in a car in the hot sun). Doing so might cause ignition, rupture, fault, fire or injury.



Before entering an area where flammable gas is generated such as a gas station, be sure to turn off the product. Do not charge the battery. Failure to observe these precautions might cause the gas to catch fire. In addition, when using the Osaifu-Keitai® payment function at a gas station, be sure to turn off the power in advance. (If FeliCa lock has been set, cancel the lock before turning off the power.)



Do not put the product in a cooking apparatus such as microwave oven or a pressure vessel. Doing so might cause ignition, rupture, fault, fire or injury.



Do not throw the product into a fire or heat it. Doing so might cause fire, rupture or fire.



Do not short-circuit the connection terminals. Do not allow conductive foreign objects (metal fragments, pencil leads, etc.) to come into contact with or get inside the connection terminals. Doing so might cause fire or a fault.



When using metal accessories, etc., take sure not to allow the metal part come in contact with the connection terminals or power outlet. Doing so might cause electric shock, fire, injury or a fault.



Do not expose the camera lens to direct sunlight for an extended period. Doing so might cause ignition, rupture or fire by the light-collecting mechanism of the lens.



The customer is not allowed to disassemble, modify or repair the product. Doing so might cause a fault, fire, electric shock, or injury. The Company is not liable even in the event of any nonconformities arising on the product or peripheral devices as a result of modification, etc. Modification of the product is in violation of the Wireless Telegraphy Act.



⚠ WARNING Be sure to read the following warnings before use.



Do not drop or subject to strong impact, such as throwing. Doing so might cause rupture, overheating, fire, or a fault.



Do not use outside when you can hear thunder. Doing so might risk lightning strikes and electric shock.



Do not let your hands, fingers and other parts of the body touch the connection terminals. Doing so might cause electric shock, injury or a fault.



If the product is damaged because it is dropped or something, and its display is cracked or internal parts are exposed, do not touch the cracked display or exposed parts with your hands. Doing so might cause electric shock or injury from damaged parts. Contact an au shop or Secure cell phone support center.



If you charge the battery while the product is wet, it might cause electric shock, short circuit, or corrosion, leading to fire due to overheating or fault.



Although this product model has waterproof property, stop use if liquid such as water gets inside the main unit from the external connection jack cover or back cover. Continued use of the product in this state might cause overheating, fire or a fault.





When removing the back cover, do not exert more than necessary force. The battery pack might jump out, for example, and cause injury or a fault.



Do not operate the product while driving an automobile or motorized bicycle, riding a bicycle or walking. Doing so may compromise traffic safety and cause an accident.



If charging is not completed after the specified charging time, stop charging. Failure to do so might cause leakage of liquid, overheating, rupture or fire.



Do not leave in places within the reach of small children. Small children might swallow small parts, etc. by mistake and choke on them, or might drop them by mistake and cause accidents or injury.



CAUTION Be sure to read the following cautions before use.



Do not store the product in places subject to direct sunlight (e.g. in automobiles), places that get hot, places that get extremely cold, and in humid or dusty places. Doing so might cause overheating, fire, deformation or a fault.



Do not leave on unstable places such as rocky stands or tilting surfaces especially while the vibration mode set. Dropping the product may cause injury or damage. Also, pay sufficient attention to impact, etc.



Do not cover or wrap the product with bedding, etc. while using or charging the product. Doing so might cause fire, fault or injury.



Do not touch the main unit or specified charging equipment for a long time while power is being supplied from an external source. Doing so might cause low-temperature burns.



The product may become hot by prolonged use especially in high-temperature environment. Be careful when using the product touching your skin for a long time, as it might cause low-temperature burns.



Do not use power outlets or wiring apparatus beyond its rating. Also, exceeding rating, for example, by connecting multiple devices to a single power strip might cause overheating and fire.



Do not use the product with the back cover removed.



Do not place near corrosive chemicals or in places where corrosive gas is generated. Doing so might cause a fault or loss of internal data.



Do not leave or store with the back cover or battery pack removed from the main unit. Doing so might allow dust or other foreign objects to get inside and cause a fault.



Do not use if there is smoke, abnormal odor or noise, excessive overheating, or other abnormalities. If an abnormality occurs, disconnect the specified charging equipment (sold separately) from the power outlet, make sure that the product is not overheating before turning the power off or removing the battery off, and contact an au shop or Secure cell phone support center. Also, if you have dropped or damaged the product, do not continue to use it in that state, and contact an au shop or Secure cell phone support center.



When using an earphone, etc. with the product, adjust the volume to an appropriate level. Setting too loud a volume or using the earphone continuously for a long period of time might adversely affect your hearing. Also, raising the volume too high might prevent you from hearing sounds around you, which might in turn lead to a traffic accident at a railroad crossing or pedestrian crossing.



When adjusting the volume when using an earphone, etc. with the product, raise the volume a little at a time. If you raise the volume too much from the outset, sudden loud noise from the earphone, etc. might adversely affect your ears.



When using the specified charging equipment or external device, insert/remove the connector straight to/from the terminal. Make sure the orientation of the connector is correct. Failure to do so might cause damage or a fault.

Main unit

WARNING Be sure to read the following warnings before use.



Do not use a cell phone while driving a car or riding a motorbike or bicycle. It may cause a traffic accident. Use of a cell phone while driving a car or motorbike is prohibited by law. Use of a cell phone while riding a bicycle may be punishable by some regulations.



Do not use this product while you are aboard an airplane. Use of electric devices transmitting radio waves in airplane is prohibited by law. Some airline companies, however, allow their passengers to use cell phones. For details, contact the airline company you use.



The product sometimes affects high-precision electronic devices. So, turn it off near such devices. (Examples of electronic devices that might be affected by the product include cardiac pacemakers, hearing aids, other electronic medical devices, fire alarms, and automatic doors. If you are using an electronic medical device, contact the device manufacturer or retailer for information about the possible affect of radio waves.)



When using the product near an implanted pacemaker, implanted cardioverter-defibrillator or other electronic medical device, radio waves might affect these units and devices. So, please observe the following.

- Those with an implanted pacemaker or implanted cardioverter-defibrillator should carry or use the product at least 22 cm away from the pacemaker or cardioverter-defibrillator.
- Turn the product off in crowded trains or other crowded places, since there may be people with a cardiac pacemaker or implanted cardioverter-defibrillator nearby.
- Pay attention to the following points when using the product inside medical institutions.
 - Do not bring the product into operating theaters, intensive-care units (ICU) and coronary care units (CCU).
 - Turn the product off in hospital wards.
 - Even if you are in a lobby, etc., be sure to turn the product off when there are electronic medical devices nearby.
 - When a medical institution has laid down designated areas where use of the product is prohibited or is not allowed to be brought in, abide by the instructions of that medical institution.
- When using electronic medical devices other than an implanted pacemaker and implanted cardioverter-defibrillator outside a medical institution (e.g. home medical treatment), check individually with the manufacturer of the electronic medical device regarding the influence of radio waves.



Stay alert to your surroundings when calling, messaging, browsing the Internet, shooting photos, playing games, watching TV (1Seg) or listening to music. Failure to do so might cause a fall or traffic accident.



Do not send data by infrared communication with the infrared port pointing toward eyes. Doing so might affect eyes. Also, sending data with the infrared port pointing toward some other infrared device might cause false operation, etc.



Do not shine the camera light/simple light in front of a person's eyes. Do not gaze directly at the light when the camera light/simple light is shining. Doing so might cause impairment of eyesight, etc. Be especially careful not to shoot small children from a very close distance.



Do not shine the camera light/simple light toward the driver of a car, motorbike or bicycle. If dazzled by the light, the driver might become unable to drive and cause an accident.



Sometimes, very rarely some people demonstrate symptoms such as temporary muscle spasms, loss of consciousness, etc. by watching repeatedly flickering screens. Those with a past history of this should consult with a physician beforehand.



CAUTION Be sure to read the following cautions before use.



Use of the main unit in an automobile might sometimes affect on-vehicle electronic devices, though this rarely happens. If this happens, stop use since this may impair safe travel.



If you feel any abnormality with your skin, immediately consult a dermatologist. Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition.
The materials of parts used on the product are as follows.

Location	Material	Finish
Outer case (LCD casing, key casing)	PC + GF resin	UV cured acrylic coating
Outer case (hinge cover LCD half, key half), back cover	PC resin	UV cured acrylic coating
Outer case (LCD rear plate)	SUS	Acrylic thermally cured coating
Outer case (hinge contact)	Polyacetal	—
Address book key, Application key, Mail key, EZ key, Cursor key, Answer key, Clear/Memo key, Power/End key, Number keys, * key, # key	PC resin	UV cured acrylic coating
Center key	Acrylic resin	—
Key plate	PET resin	—
Cushion (under number keys)	Silicone rubber	—
Window panel (main), Infrared port window, Camera plate	Acrylic resin	Chemical hardening
Window panel (sub), Information/Charge indicator window	Acrylic resin	Evaporation + UV cured acrylic coating
Manner/Shutter key (side key)	PC resin	—
External connection jack cover	PC resin + TPE resin	UV cured acrylic coating
Charging terminals	Phosphor bronze	Gold plating (base layer: nickel)



Do not bring the product close to magnetized objects such as cash cards, floppy disks, credit cards, and prepaid cards. Doing so might result in loss of recorded information.



Do not allow liquids, metal objects, burnable items, and other foreign matter to get inside the microSD memory card slot. Failure to do so might cause fire, electric shock or a fault.



Do not swing the product around by holding an attached earphone (sold separately), hand strap, etc. Doing so might cause injury or other accident or damage.



Use the product with the covers of external connection jack, etc. closed. If the covers are open, dirt or water may get inside causing a fault.



If you have a weak heart, be careful when setting the incoming vibration and ringtone volume to prevent adverse effects on your heart.



Pay attention to items becoming stuck to the main unit. The speaker uses magnets, and so thumbtacks and pins, craft knife blades, staples, and other metal objects sometimes become stuck to the main unit, and cause unexpected injury. Before using the product, be sure to check that there are no foreign objects on the speaker or other parts.



Do not put the product directly on sand at a beach, etc. Sand or other small particles might get inside the microphone or speaker, causing the volume to drop. If sand gets inside the main unit, it might cause overheating or a fault.



When using the product for calling or data communication, be careful not to keep the product in direct contact with your skin for a prolonged period, or not to cover the product with paper, cloth, bedding, etc. The main unit might get hot, causing fire, burns or a fault.

Battery pack



Li-ion 00

(The battery pack of this product is a lithium-ion battery.)

The battery pack is not fully charged at the time of purchase. Charge the battery before using the product.



DANGER

Be sure to read the following hazards before use.



Do not short-circuit the positive (+) and negative (-) terminals of the battery pack.



Connect the battery pack to this product in the correct orientation. Connecting in an incorrect orientation might cause rupture, fire or overheating. Do not try to forcibly connect the battery pack, instead thoroughly check the connection terminals carefully before connection.



Do not puncture the battery pack with a nail, hit it with a hammer or step on it. Doing so might cause fire or damage.



Do not allow metal objects (such as necklaces and hairpins) to come in contact with the connection terminals when carrying or storing the battery pack. Doing so might cause fire or a fault due to a short circuit.



Do not disassemble, modify or directly solder the battery pack. Doing so might cause spilling of the battery liquid resulting in an accident such as loss of eyesight if it gets into eyes, or cause overheating, fire or rupture.



Do not use a battery pack that has been dropped, stepped on, damaged, or leaking battery liquid. Immediately move the battery pack away from fire if you notice leakage of liquid or unusual odor. Failure to do so might cause the leaked liquid to catch fire resulting in fire or rupture.



Do not wet the battery pack with water, seawater, pet urine, etc. A wet battery pack might cause overheating, rupture or fire. If you drop the product into water by mistake, immediately turn off the power, remove the battery pack, and contact an au shop or Secure cell phone support center. Never charge the wet battery pack.



If the leaked liquid gets on your skin or clothes, immediately rinse it off with water to avoid injury. If the liquid gets into your eyes, do not rub but wash your eyes with water, and immediately consult a doctor to avoid the risk of losing your eyesight. If the liquid gets on a device, wipe it off without touching it.



The battery pack is a consumable item. If the performance of a battery pack does not recover (e.g. the usable time after each charge has become extremely short), the battery pack is at the end of service life, so stop use and buy a new one of the specified type. Failure to do so might cause overheating, fire, rupture or leakage. Note that the length of service life varies depending on the usage condition, etc.



Be careful not to have the battery pack bitten by your pet. It might cause leakage, overheating, rupture or ignition of the battery pack.

Charging equipment



WARNING Be sure to read the following warnings before use.



Do not use at other voltages than the specified power supply voltage. Doing so might cause fire, overheating or electric shock.

- Desktop holder (KYY06PUA): 5.0 VDC
- Common AC adapter 04 (sold separately): 100 VAC to 240 VAC
- AC adapters other than the above allowing charging overseas (sold separately): 100 VAC to 240 VAC
- Common DC adapter 03 (sold separately): 12/24 VDC (for negative-grounded vehicles only)



Firmly insert the plug of the specified charging equipment (sold separately) into the power outlet down to the base of its pins. Incomplete insertion of the power plug might result in electric shock or fire caused by overheating and fire. Do not use damaged adapters or loose power outlets.



If the fuse in the common DC adapter 03 (sold separately) blows, replace it with a fuse of the specified type (250 V, 1 A). Replacing with a different type of fuse might cause overheating or fire. (For information about fuse replacement, carefully read the manual for the common DC adapter 03 (sold separately).)



Do not damage, modify, twist, pull or place a heavy object on the power cord of the specified charging equipment (sold separately). Do not use a damaged cord. Doing so might cause an electric shock, short circuit or fire.



Do not let your hands, fingers and other parts of the body touch the connection terminals. Doing so might cause electric shock, injury or a fault.



If you hear thunder, do not touch the power plug. Doing so might cause an electric shock as a result of a lightning strike.



Before cleaning the specified charging equipment (sold separately), unplug its power plug from the outlet or cigarette lighter socket. If the plug remains plugged in when you clean the equipment, it might cause an electric shock or short circuit. Also, wipe off dust on the charging equipment's power plug. If the plug is left covered with dust, it might cause fire.



Wipe off dust on the power plug. Failure to do so might cause fire, burns or electric shock.



Install and position in-car devices where they do not hinder driving or safety equipment such as airbags. Failure to do so might cause a traffic accident. Install in-car devices following the instructions of their manuals.



When the specified charging equipment (sold separately) is not to be used for a long time, unplug it from the power outlet. Failure to do so might cause electric shock, fire or a fault.



Do not use in places subject to direct splashing with water, pet urine or other liquids. Doing so might result in overheating, fire, electric shock, or faults resulting from short circuit. In the event that the product is splashed with liquid, immediately unplug the specified charging equipment (sold separately).



CAUTION Be sure to read the following cautions before use.



Do not use in humid places such as bath areas, or plug/unplug the specified charging equipment (sold separately) with wet hands. Doing so might cause electric shock or a fault.



Charge the battery in a stable place especially while the vibration mode set. If placed on an inclined surface or wobbly stand, the product might fall causing injury or damage. In addition, do not cover or wrap the product with a cloth or bedding. Doing so might cause fire or a fault.



When unplugging the plug of the specified charging equipment (sold separately) from the power outlet, hold and pull the power plug. If you pull the cord, the cord might be damaged.



Do not use the common DC adapter 03 (sold separately) with the car engine stopped. Doing so might result in draining of the car battery.



Do not leave the specified charging equipment (sold separately) connected to the main unit with the battery pack removed. Doing so might cause fire or electric shock.



Immediately discontinue use if a skin abnormality occurs, and consult a dermatologist. Itchiness, irritation, a rash, etc. may develop depending on your constitution/health. Materials used in each part of the desktop holder (KYY06PUA) are as follows.

■ Desktop holder (KYY06PUA)

Location	Material	Finish
Outer case	ABS resin	—
Lever, knob	POM resin	—
Charging terminals	Phosphor bronze	Gold plating (base layer:nickel)

micro au IC-Card 02

WARNING Be sure to read the following warnings before use.



Do not put the micro au IC-Card 02 in a cooking apparatus such as a microwave oven or a pressure vessel. Doing so might cause melting, overheating, fuming, loss of data or a fault.

CAUTION Be sure to read the following cautions before use.



Be careful not to injure your hand or finger when attaching/removing the micro au IC-Card 02.



Use only the devices specified by the Company to insert the micro au IC-Card 02 in. Using a device not specified by the Company might cause loss of data or a fault.
For the specified devices, contact an au shop or Customer Service Center.



Do not disassemble or modify the micro au IC-Card 02. Doing so might cause loss of data or a fault.



Do not use or leave the micro au IC-Card 02 in hot places such as by the fire or a heater. Doing so might cause melting, overheating, fuming, loss of data or a fault.



Do not throw the micro au IC-Card 02 into a fire or heat it. Doing so might cause melting, overheating, fuming, loss of data or a fault.



Do not touch the IC (metal) part of the micro au IC-Card 02 or short-circuit it. Doing so might cause loss of data or a fault.



Do not drop the micro au IC-Card 02 or subject it to strong impact. Doing so might cause a fault.



Do not fold, bend or place a heavy object on the micro au IC-Card 02. Doing so might cause a fault.



Do not wet the micro au IC-Card 02. Doing so might cause a fault.



Do not scratch the IC (metal) part of the micro au IC-Card 02. Doing so might cause a fault.



Do not store the micro au IC-Card 02 in dusty places. Doing so might cause a fault.



Do not store the micro au IC-Card 02 in places exposed to direct sunlight or hot and humid places. Doing so might cause a fault.



Store the micro au IC-Card 02 out of reach of small children. Failure to do so might cause injury or asphyxiation, etc. if they accidentally swallow and choke on it.

Handling precautions

These precautions are provided to ensure that performance can be fully demonstrated. Thoroughly read these precautions to ensure correct use.

■ Precautions common to the main unit, battery pack, back cover, charging equipment, micro au IC-Card 02, peripheral devices

- Do not apply excessive force to the product during use. Be sure not to put the product into a tightly packed bag or place a heavy object on the product in a bag. Sitting on the product in your pocket might damage the display or internal circuit board resulting in a malfunction.
Keeping an external device connected to the external connection jack might damage the connector resulting in a malfunction. Such damage and malfunction are not covered by the warranty, even if there is no external damage.
- To ensure the water resistance (equivalent to IPX5 and IPX8) of this product, use the product with the specified back cover, and also use with the external connection jack cover tightly closed.
Note that the water resistance is not guaranteed for all usage conditions. Do not allow water to get inside the product or splash water on the battery pack, charging equipment or optional accessories. Do not attach/remove the back cover or open/close the external connection jack cover in the rain or with any water on the surface of the product. Doing so might cause water intrusion resulting in internal corrosion.
Malfunctions determined to be caused by water intrusion are not covered by the warranty.
- Do not use the product in extremely hot, cold or humid places. (Use within an ambient temperature range of 5°C to 35°C and humidity range of 35% to 85%.)
 - Charging equipment
 - Peripheral devices

- Do not use the product in extremely hot, cold or humid places. (Use within an ambient temperature range of 5°C to 35°C and humidity range of 35% to 90%. Temporary use at 36°C to 40°C is allowed.)
 - Product main unit
 - Battery pack, micro au IC-Card 02 (installed in product main unit)
- Do not use in places subject to lots of dust or vibration.
- Clean the connection terminals with dry cotton swabs, etc. every now and then. Soiled terminals might cause poor connection. Do not exert a strong force to clean the connection terminals to prevent deformation.
- Clean the product with a soft dry cloth (such as the type used for eyeglasses). Forceful rubbing with a dry cloth may scratch the display. The display may be stained if splash or smear is left attached to the surface. Wiping the product using alcohol, thinner, benzene, detergent, etc. might erase the printing on the outer casing or cause discoloration.
- Use as far away as possible from land-line phones, TVs and radios. Use nearby might affect them.
- The product may become warm while charging or during other operations, depending on the situation, but this is not abnormal.
- When the product is used by a child, parents or guardians should thoroughly read this manual and teach the child how to use it.
- Turn off the power before removing the battery pack. If you remove the battery pack with the power on, saved data might be altered or lost.
- Do not place stickers, etc. on the main unit. Doing so might prevent sound from being emitted or prevent the other party from hearing you.

Main unit

- Do not forcefully press, tap or intentionally subject the display to strong impact. Doing so might cause scratching or damage.
- Do not forcefully press your fingernails, sharp objects or hard objects against keys or display surface. Doing so might cause scratching or damage.
- Do not remove the stickers printed with the serial numbers that can be seen when the back cover is removed. These stickers prove that the product and the communication module you are using comply with the Wireless Telegraphy Act and Telecommunications Operations Act.
- Never use modified au cell phones. Use of a modified device violates the Radio Law.
This product has acquired the certification of conformity with technical regulations for the specified radio station based on the Radio Law, and the "Technical Conformity Mark" is printed on the nameplate of the product as a certificate.
If the screws of the product are removed and modifications are made to the internal components, the certification of conformity with technical regulations will become invalid. Never use the product without the valid certification. Doing so violates the Radio Law.
- To prevent unlawful modification, the product has been designed so that it cannot be easily disassembled. Modifying the product is prohibited by the Radio Law.
- Contents saved in this product, such as phone book entries, e-mail and favorites, might be altered or lost by an accident, fault, repair or other handling. Be sure to keep a copy of important contents. Note that the Company assumes no responsibility for any damages or lost profits resulting from altered or lost contents.
- Note that content data (both charged or free content) saved on the product cannot be returned to the customer when the product is replaced for repair of a fault, for example.
- This product uses liquid crystal for its display. The display response speed may become slow when the ambient temperature is low, which is due to the property of liquid crystal and not a malfunction. The display response speed will return to normal at room temperature.
- Although the display used on the product is made using high-precision technology, some pixels (dots) might be lit or out at all times. This is not a malfunction.
- Take care not to inconvenience people around you when you use the product in a public place.
- You are recommended to store copies of individual data such as photos you took, videos and music in your PC by sending each file as mail attachment, etc. Note, however, that you may not be able to make copies of some copyrighted data even by the above-mentioned means.
- Take care not to place magnetized items such as magnetic cards, speakers and TV sets near the product, as it might cause malfunction.
Putting strong magnetism close to the product might cause false operation.
- To prevent unauthorized use in case of theft or loss, this product is locked so that it cannot be used unless the legitimate user's micro au IC-Card 02 is inserted. If the user is changed to some other person, the new user should bring the micro au IC-Card 02 to an au shop or PiPiT. Note that a fee is charged for ownership change.
- When you put the product in your pocket or bag, take care so that the display does not come in contact with metal objects or other hard objects, as it might cause scratching or damage. Also, be careful not to scratch or damage the display by using a strap whose metal or other hard part comes in contact with the display.
- When suddenly brought into a warm place from a cold place, or when in a humid location, or when used where temperature suddenly changes (e.g. near the air discharge port of an air conditioner), water droplets (i.e. condensation) sometimes are formed inside the product. Note that when used under conditions such as this, humidity might cause corrosion or a fault.
- When wiping the display, wipe with a soft, dry cloth. Use of a moistened cloth, glass cleaner or other similar liquid might cause a fault.
- When connecting/disconnecting an external device to/from the external connection jack, make sure that the connector/plug on the device is straight with the external connection jack.
- Note that applying unnecessary force with the USB cable connected to the USB connector might cause damage.

- Do not discard the product together with regular trash. Please cooperate in the collection of the product when it is no longer needed to protect the environment and effectively use resources. Old products are collected at au shops and other places.
- Insert only a microSD memory card into the microSD memory card slot on the product.
- Do not exert excessive force when attaching/removing a microSD memory card. Doing so might injure your hands or fingers.
- While writing/reading data to/from a microSD memory card, do not subject the product to vibration or impact, remove the battery pack or turn off the power. Doing so might cause loss of data or a fault.
- Take care that fingers, etc. do not cover the microphone during a call. The other party might have difficulty hearing you.
- When using handsfree call, take care to keep the speaker at a safe distance from your ears, as the speaker volume may be too loud.
- Do not cover the sensor with your finger or put a sticker on it. Doing so may hinder the sensor from detecting ambient conditions and functioning correctly.

Battery pack

- Use in very hot or cold environments, for example, when left in an automobile with the windows closed in summer, will cause the battery capacity to drop and shorten the available battery usage time. This will also shorten the battery pack's service life. Try to use the battery pack as far as possible at room temperature.
- When the battery pack is not to be used for a long time, remove the battery pack from the main unit and store it away from hot and humid places.
- Charge the battery before using the product for the first time after purchase, or if you have not used the product for a long time.
- The battery pack is a consumable item. If the performance of a battery pack does not recover after charge, the battery pack is at the end of service life, so buy a new one of the specified type. Note that the length of service life varies depending on the usage condition, etc.
- Do not discard battery packs together with regular trash. Please cooperate in the collection of used battery packs to protect the environment and effectively use resources. au shops and other retailers collect used battery packs.
- Battery packs sometimes swell up as they approach the end of their service life. This is due to the properties of lithium-ion batteries, and is not a problem in terms of safety.

AC adapter

- When not using the specified charging equipment (sold separately), remove the plug from the power outlet.
- Do not wrap the cord of the specified charging equipment (sold separately) around the adapter itself. Doing so might cause electric shock, overheating or fire.
- Do not forcibly bend the plug of the specified charging equipment (sold separately) or the connection between the connector and power cord. Doing so might cause electric shock, overheating or fire.

micro au IC-Card 02

- The micro au IC-Card 02 is lent to you by au. In case of loss or damage, the card will be replaced at your expense. When malfunction is suspected, or in case of theft or loss, contact an au shop or PiPiT.
- Do not forcibly remove or insert the micro au IC-Card 02. Be careful not to exert excessive force when inserting the card into your au cell phone.
- You are responsible for any damage caused by inserting your micro au IC-Card 02 into some other IC card reader/writer, etc.
- Keep the IC (metal) part of your micro au IC-Card 02 clean. Wipe the card with a dry, soft cloth (such as for cleaning eyeglasses) for cleaning.
- Do not put stickers, etc. on the micro au IC-Card 02.
- Do not use Nano IC Card (LTE) with the card adapter. Doing so might cause a fault.

Camera

- When using the camera, follow common rules of etiquette regarding camera use.
- Image data might be altered or lost due to malfunction, repair or mishandling of this product. The Company takes no responsibility for recovery of altered or lost data, damages resulting from altered or lost data, and lost profits.
- When photographing important occasions (such as a wedding), take a trial shot and check the shot image to make sure it is correctly shot.
- Do not use the camera for recording commercially available books or information of which photographing is not allowed.
- Do not leave the camera lens exposed to direct sunlight. Imaging elements might be discolored or burnt.

Music, videos and TV (1seg)

- Do not listen to music or watch videos or TV (1seg) while driving a car or motorbike, or riding a bicycle. Use of cell phones while driving a car or motorbike is prohibited by law. (Use of cell phones while riding a bicycle may also be punishable by law.) In addition, stay alert to the traffic around you even when walking. Surrounding sounds may not be heard clearly, and gazing at the screen might distract your attention causing a traffic accident. Be especially careful at railroad crossings, station platform and pedestrian crossings.
- Take care not to listen at ear-splitting volume for a long time, as it might affect hearing.
- Be careful of sound leakage from earphones in trains or other places with many people around you.

Copyrights and rights of portrait

- You are not allowed to copy, distribute, publish, modify or edit the data you shot, recorded or downloaded using this product without consent of the copyright holder, except for personal use, under the copyright law. In addition, do not use or modify portraits or names of other individuals without their consent, as it might infringe on rights of portrait. Note that shooting and recording may be restricted at some live performances, shows and exhibitions even for personal use.
- Be careful about the copyright and portrait right when posting photos you shot, etc. on Internet homepages.

Backup content on the product

- Please back up important content recorded or downloaded to the product to an outside source. Content recorded to memory on the product sometimes disappears or is altered by unexpected factors, such as static electricity or a fault, repair, mishandling, etc.
* How to make backups: Store important data such as Phone Book data, music, shot photos and videos on microSD memory cards. You can also send files as mail attachment or transfer to your PC. Note, however, that there are some data that cannot be copied by using these means.

Notes on waterproof, dustproof and shock-resistant properties

This product has a waterproof property equivalent to IPX5^{*1} and IPX8^{*2}, as well as a dustproof property equivalent to IP5X^{*3} on the condition that the external connection jack cover and back cover are securely attached (based on in-house testing).

While drop testing has been carried out in accordance with MIL-STD-810G Method 516.6:Shock-Procedure IV^{*4} as formulated by the U.S. Department of Defense, this does not guarantee resistance to all instances of shock.

Specifically, you can make calls holding the product with wet hands in the rain (less than 20 mm per hour) without umbrella, as well as use the product in a place with water such as a bathroom or kitchen.

Before using the product, thoroughly read "Important items to remember before use" and "Tips for comfortable use" to ensure correct use. Failure to follow the contents described in these sections may cause intrusion of water, sand or other foreign material, resulting in overheating, fire, electric shock, injury or a fault.


- ^{*1} IPX5 equivalent means that the product will maintain its operability as a phone even if it is sprayed with water from a 6.3 mm diameter nozzle at a distance of about 3 meters for more than 3 minutes at a rate of about 12.5 liters per minute from any direction.
 - ^{*2} IPX8 equivalent means that the product will maintain its operability as a phone with no water getting inside the main unit even if it is gently submerged in a tank of still tap water at room temperature to a depth of 1.5 meter for about 30 minutes.
 - ^{*3} IP5X equivalent means that the product will securely maintain its operability as a phone even after it has been placed in an apparatus with grit and dust of diameters of 75 μ m or less and shaken for 8 hours.
 - ^{*4} Drop testing (in which the product is dropped in 26 directions from a height of 1.22 m onto plywood (lauan)) was conducted in accordance with MIL-STD-810G Method 516.6:Shock-Procedure IV formulated by the U.S. Department of Defense.
- Shock-resistant property of this product is based on the assumption that it is used in everyday life. Therefore, the product might break if it receives excessive impact

such as being thrown or dropped forcibly. Note also that the product gets scratches, etc. by falling impact even though its functionality of the main unit remains intact.

Since operation of the product on each usage scene was confirmed based on the above assumption, proper operation of the product in every possible condition during actual use is not guaranteed. Malfunctions determined to be caused by mishandling by the customer are not covered by the warranty.


Important items to remember before use

- Make sure that the external connection jack cover is firmly closed, and the back cover is securely attached.
- Waterproofness is only effective when the covers are securely closed.
- Just a small particle (a hair, etc.) on the seals can cause water leaks.
- Do not open/close the external connection jack cover or back cover if the main unit or your hands are wet.



How to close the external connection jack cover


After stowing the cover hinge, press on the external connection jack cover ① evenly with the flat part of your finger. Then, rub your finger over the cover in the direction of arrow ② to ensure that the cover is not partially open.



Closing the back cover

Close firmly so that the back cover is not raised.

- ① Place the back cover aligning its tabs with the grooves of the main unit.
- ② Push the back cover in the direction of the arrow.
- ③ Press and slide your finger over the circumference of the back cover in the direction of the arrow to firmly attach it.



- Do not immerse the product in water with soap, detergent or bath salts in it.
- Do not immerse the product in seawater, a swimming pool or hot spring.
- Do not immerse the product in any liquid (alcohol, etc.) other than water.
- Do not place the product directly on sand at a beach, etc. Grains of sand or other small particles might get into the microphone or speaker causing the volume to drop. And if sand gets inside the main unit from the hinge part, it might cause overheating or a fault.
- Do not use the product underwater.
- Do not leave the product in a humid place such as a bathroom or kitchen for an extended period of time.



Soap, detergent,
bath salts



Seawater



Pool water



Hot spring



Sand, mud

Tips for comfortable use

- Once the product gets wet, water may remain in gaps of the main unit. Shake the product well to drain water. Especially make sure to drain water remaining in the back cover, key parts, and charging terminals.
- Even after water is drained, the inner parts might be still wet. Although you can use the product, do not place it near things that must not get wet. Take care not to wet your clothes, bag or contents of the bag.
- Drain water if it becomes temporarily hard to hear the sound due to water remaining in the microphone.

Notes on various usage scenes

<In the rain>

You can make calls holding the product with wet hands in the rain without umbrella.

- The rain in this case means a moderately-heavy rain (less than 20 mm per hour).
- Never open/close the external connection jack cover or back cover if the product is exposed to rain, or your hands are wet.

<In the shower>

You can make calls holding the product with wet hands while taking a shower.

- Avoid spraying the product with high-pressure water, as the product is not designed to withstand high water pressure.

<Washing>

You can wash the product under a mild flow (up to 6 liters per minute) of tap water at room temperature (5°C to 35°C) at a distance of about 10 cm from the faucet or showerhead.

- Do not spray the product with high-pressure water or submerge it in water for extended periods of time, as the product is not designed to withstand high water pressure.
- Make sure that the back cover is tightly closed, and holding the external connection jack cover so that it does not open, wash the product with your hands. Do not use a brush or sponge.
- Do not wash the product in a washing machine or ultrasound bath.
- Do not splash the product with or immerse it in soap water, detergent water, etc. other than tap water.

<In the bath>

You can use the product in a bathroom.

- Although you can make calls with wet hands, do not immerse the product into a bathtub. The product is not resistant to high temperatures.
- Do not use the product in a bathroom for an extended period of time. The product is not moistureproof.
- Do not immerse the product in hot spring water, soap water, detergent water, or water with bath salts in it. Also, do not use the product underwater. Doing so may cause a fault.
- Extreme changes in temperature cause condensation. Wait until the main unit reaches room temperature before you bring the product from a cold place into a warm bathroom.
- If condensation occurs inside the display, leave the product at room temperature for a while until condensation is cleared.
- When viewing 1Seg, place the product on a stable surface.
- Do not splash the product with hot water. The product is not resistant to high temperatures.
- Do not bring the desktop holder (KYY06PUA) or AC adapter (sold separately) into a bathroom.

<Poolside>

- Do not immerse or drop in pool water. Do not use under water.
- Pool water contains disinfecting chlorine. If exposed to pool water, immediately wash off with room temperature tap water*. Do not use a brush.
- * Rather weak water flow (less than 6 L/min.)
- When viewing 1Seg, place the product on a stable surface.

<In the kitchen>

You can use the product in the kitchen and other places where water is used.

- Do not splash the product with or immerse it in soap water, detergent water, seasonings, juices, etc. other than tap water.
- Do not immerse the product in or splash it with boiling water. The product is not resistant to hot temperatures.
- Do not place the product where it gets extremely hot or cold such as near a stove or in a refrigerator.
- When viewing 1Seg, place the product on a stable surface.

■ Common precautions**External connection jack cover, back cover**

Make sure that the external connection jack cover is firmly closed, and the back cover is securely attached. Just a small particle (a hair, grain of sand, etc.) on the seals can cause water leaks.

Do not open/close the external connection jack cover or attach/remove the back cover with gloved hands. Just a small particle (a hair, grain of sand, etc.) on the seals can cause water leaks. Wipe off any minuscule droplets of water or dirt with a clean dry cloth before closing the covers.

If the external connection jack cover or back cover is deteriorated or damaged, the waterproof property becomes ineffective. In such case, contact an au shop near you or Secure cell phone support center.

If any liquid other than plain water gets on the product

If any liquid other than plain water (e.g. seawater, detergent, alcohol) gets on the product, immediately rinse it with plain water.

You can wash the product under a mild flow (up to 6 liters per minute) of tap water at room temperature (5°C to 35°C) at a distance of about 10 cm from the faucet or showerhead.

If the product gets dirty, wash it with your hands holding the back cover and external connection jack cover so that they do not open. Do not use a brush or sponge.

After the product gets wet

After the product gets wet, drain water, and wipe the main unit and the back cover with a clean dry cloth without removing the back cover.

In cold climates, water on the main unit may turn to frost. Using the product with frost may cause a fault. Do not leave the product without wiping off water. (No special measures against condensation have been implemented in this product.)

Rubber seals

The rubber seals around the external connection jack cover and on the main unit when the back cover is removed are important to maintaining the waterproof property. Do not damage or remove the rubber seals.

When closing the external connection jack cover or back cover, take care not to get the rubber seals caught. Forcibly closing the cover with the rubber seals caught may damage them resulting in loss of waterproof property. Just a small particle (a hair, grain of sand, etc.) on the seals can cause water leak.

If any liquid other than plain water (e.g. alcohol) gets on the rubber seals, it may cause deterioration in durability.

Do not insert sharp objects into gaps around the external connection jack cover and back cover. Doing so might damage or deform the product or damage the rubber seals, causing water leak.

It is recommended to replace the parts for maintaining waterproof property once every 2 years regardless of whether any abnormality is present. For information on part replacement, contact an au shop near you or Secure cell phone support center.

Charging

Never charge the battery if the main unit is wet.

The supplied and optional accessories are not waterproof.

Waterproof property

Do not use the product in places where it may be sprayed with high-pressure water (e.g. near a faucet or showerhead) or submerge it in water for extended periods of time, as the product is not designed to withstand high water pressure. Also, do not expose the product to a water flow stronger than the specified flow rate (i.e. 6 liters per minute from a faucet or showerhead, at which you might even feel pain in the skin). Doing so might cause a fault, even though the product has a waterproof property equivalent to IPX5. Do not wash the product in a washing machine or ultrasound bath.

This product does not float on water.

Heat resistance

Do not use the product in places where boiling water may splash on it, in saunas or near hot air (e.g. hairdryer). The product is not resistant to high temperatures.

Shock

Intentionally subjecting the product to extreme force such as throwing it or letting it drop might break the product. While performance of the main unit may not be affected, dropping or subjecting it to shock produces scratches, etc.


Do not jab the microphone, speaker, etc. with a cotton swab or any sharp object. Doing so might damage or deform the main unit causing water intrusion.

■ Draining water after wetting the product

As some parts of this product are not watertight, if you use the product after it gets wet, water remaining in those parts might wet your clothes or bag, or the sound might become hard to hear.


Follow the steps below to drain water.

- 1 Carefully wipe away all water on the cell phone with a lint-free, clean, dry cloth.**




2 Shake the cell phone

- ① Hold the cell phone firmly, and shake as shown until there is no more wetting.
 - * Make sure it is safe around you before shaking.
 - * Hold firmly and do not let the cell phone fly out of your hand.



- ② Wipe away any wetting.
 - * Since it is especially difficult to drain water from the microphone and speaker, turn the cell phone so they are faced downward and the cloth is pressed into them.
- ③ Leave on a dry towel or cloth at room temperature for a while.

3 Gently press the cell phone into a lint-free, clean, dry cloth to wipe away any water in gaps such as in the microphone, speaker, hinge, charging terminals, etc.



4 After removing as much water as possible from the cell phone, leave at room temperature for at least one hour to dry.

Water may still remain in the cell phone even after following the preceding steps. Do not leave the cell phone near items you do not want to get wet. Clothing, carrybag, etc. may also become wet.

■Precautions on charging

The supplied and optional accessories are not waterproof. Be sure to check the following points before and after charging.

- Never charge the battery if the main unit is wet. Doing so might cause electric shock or short circuit resulting in fire or a fault.
- Check that the main unit is not wet. If you are charging the battery just after the product gets wet, drain water well and wipe remaining water off with a clean dry cloth before placing it in the desktop holder or opening the external connection jack cover.
- If you charge the battery with the external connection jack cover open, be sure to tightly close the cover when charging is finished. We recommend using the desktop holder (KYY06PUA) and AC adapter (sold separately) to charge the battery to prevent water, sand, and foreign particles from entering from the external connection jack.
- Do not touch the specified charging equipment with wet hands. Doing so might cause electric shock.
- Do not splash water over the specified charging equipment when using them. Do not use them near water such as in a bathroom, shower room, kitchen or washroom. Doing so might cause fire, electric shock or a fault. Do not bring them into a bathroom, etc. even when you are not charging with them.

Notes on using Bluetooth® functions

Frequency band

Bluetooth® functions of the au cell phones use frequencies in the 2.4 GHz band ranging from 2.402 GHz to 2.480 GHz.



Bluetooth® function: 2.4FH1

This product uses the 2.4 GHz band. FH-SS is used as the modulation scheme. The interference distance is about 10 m or less.

- The bands of mobile unit identification devices cannot be avoided.

Precautions about Bluetooth®

- The Bluetooth® function of this product conforms to the domestic standards of Japan and FCC standards, and has been certified.
- The 2.4 GHz band used by Bluetooth® devices is shared by various other devices. For this reason, Bluetooth® device use technologies for minimizing effects from other devices using the same radio frequency band. In some cases, however, the communication speed and connectable range may be decreased, or disconnection may occur, due to interference by other devices.
- The communication speed and connectable range vary depending on the distance between communication devices, obstacles and the Bluetooth® devices used.

Bluetooth® precautions

The frequencies used by the Bluetooth® function of this product are in the 2.4 GHz band. In this frequency band, other similar wireless stations, in-plant wireless stations for mobile unit identification that require a license for use, such as factory production lines, specific smallpower wireless stations that do not require licenses, amateur wireless stations (collectively called “other wireless stations” from here on) are operated in addition to home electrical appliances such as microwave ovens, devices for industrial, scientific and medical devices.

1. Before using this product, make sure that “other wireless stations” are not in operation nearby.
2. In the event that instances of radio wave interference have occurred between this product and “other wireless stations”, immediately either relocate this product or stop operation of the device (stop emission of radio waves).
3. If you are unclear on any points or are troubled by anything, contact an au shop or Customer Service Center.

- Connections between this product and all other Bluetooth® devices have not been confirmed. Therefore, connections with all Bluetooth® devices are not guaranteed.
- This product supports security features for wireless communications that are compliant with the Bluetooth® standard specifications, but the security may not be sufficient depending on the usage environment and configuration. Be careful when making data communication using Bluetooth® function.
- The Company assumes no responsibility for leakage of data or information that may occur during Bluetooth® communication.

Notes on Cell Phone Use

Cell Phone Etiquette

The cell phone always emits weak radio waves when power is on.

Use the cell phone in an enjoyable and safe manner without forgetting to be considerate of others around you.

- **Use of cell phones is not allowed in some places.**
 - Do not use the cell phone while you are driving. Doing so is both dangerous and prohibited by law.
 - Using a cell phone in an aircraft is prohibited by law. Set Airplane Mode to *ON* and turn the cell phone power off.
- **Radio waves from cell phones may interfere with medical electrical equipment.**
 - Some people close to you in crowded places such as packed trains may be using a cardiac pacemaker. Turn the cell phone off in such places.
 - Abide by the rules of hospitals and other medical institutions where it is forbidden to use or carry cell phones.
- **Be considerate of where you use the cell phone and how loudly you talk.**
 - Do not make calls in theaters, museums, libraries, and other similar places. Turn power off or turn on manner mode not to disturb others around you by ring tones.
 - Do not use the cell phone on a street where you might interrupt the flow of pedestrians.
 - Move to areas where you will not inconvenience others on trains or in hotel lobbies.
 - Refrain from talking in a loud voice.

- Obtain the permission of other people before you take their photos with the cell phone's camera.
- Do not record information with the cell phone's camera in bookstores and other locations where taking photos is not permitted.

Do Not Use the Cell Phone While Driving!

Turn off your cell phone or put it in Drive Mode while driving.




Do not use the cell phone while driving a car/motorcycle or riding a bicycle. It may result in a traffic accident. Using a cell phone while driving is prohibited by law. Using a cell phone while riding a bicycle may also be punishable by law.

Prohibited!

- Looking at a cell phone display
- Talking on a cell phone while holding it

Drive Mode

In Drive Mode, a Japanese message meaning "I'm driving now, so I can't answer your call." is played when a call is received, and asks the caller to leave a message on the answer memo.

When the standby screen is displayed, press , use  to select *Drive Mode*, and then press  (OK).

Disaster Message Board Service

When a large scale disaster occurs, you can register your safety information from EZweb. The registered information can be referred from anywhere in Japan from EZweb or Internet.

Registering safety information

- When a large scale disaster occurs, from an au phone, you can register your safety information (i.e. your condition and comments) to the 災害用伝言板 (Disaster Message Board) created on the EZweb.

- After registration of your safety information, e-mail is sent to your family or acquaintances you have previously designated to notify that your safety information has been uploaded to the 災害用伝言板 (Disaster Message Board).

Inquiring for safety information

- You can inquire for safety information of a person by entering his/her phone number from EZweb or Internet.*
* To inquire from other carriers' cell phone, a PHS or PC, access "<http://dengon.ezweb.ne.jp/>".

Access

E ⇒ Top Menu/Search ⇒ 災害用伝言板
義援金サイト 復興支援 au ID 天気
占い設定 (Disaster Message Board
Donations site Recovery aid au ID
Weather Horoscope settings) ⇒ 災害用伝
言板 (Disaster Message Board)

<http://dengon.ezweb.ne.jp/>

- Registered information is stored until the service set up for the disaster ends.
- The maximum available number of registrations is 10 per phone number. When the number of registrations exceeds 10, the oldest one is overwritten.
- To view the Disaster Message Board in English, select *English* from the top menu of the Disaster Message Board.

Contents

Introduction

Illustrations and Screenshots in This Manual 1

Safety Precautions/Notes on waterproof, dustproof and shock-resistant properties 2

Exemptions	2
Safety Precautions (Observe Strictly)	3
Handling precautions	12
Notes on waterproof, dustproof and shock-resistant properties.....	16
Notes on using Bluetooth® functions	21

Notes on Cell Phone Use 23

Cell Phone Etiquette	23
Do Not Use the Cell Phone While Driving!	23
Disaster Message Board Service	24

Contents 25

Getting Ready 27

Checking the Contents of the Box	27
Names of Parts	28
Smart Sonic Receiver	29
Charging the Battery Pack	30
Learning the Basics	31
Turning On Power	32
Switching the Display Language to English	32

Initial Setup of E-mail and EZweb	33
Checking Your Phone Number and E-mail Address ...	33
Display Indicators	34
Using Menu	36
Changing Your E-mail Address	37
Security Code and Passwords	38

Making and Answering Calls 39

Making a Call	39
Making an International Call	39
Answering a Call	40
Returning a Call (Outgoing History/Incoming History) ...	40
One-ring Calls	40
Adjusting the Earpiece Volume during a Call	41
Turning On Manner Mode	41
Changing the Incoming Ring Tone	41
Adjusting the Incoming Ring Tone Volume	42
Turning On the Answer Memo	42

Global Function 44

Setting the Area	44
Obtaining the Latest PRL (Preferred Roaming List) ...	44
Calling Japan from Overseas	45

Character Input 46

Character Entry Modes	46
Entering Alphanumeric Characters	46
Entering E-mail Addresses	47
Entering Pictograms	48

Phone Book 49

Saving a Phone Book Entry	49
Dialing from the Phone Book	49
Editing Phone Book Entries	49
Saving a Phone Number from the Incoming or Outgoing History	50

Mail 51

Using E-mail	51
Creating and Sending E-mail Messages	51
Reading Received E-mail Messages	52
Reading an E-mail Message with an Attached Photo or Movie	52
Replying to Received E-mail Messages	52
Rejecting Spam	53
Using C-mail	54
Creating and Sending C-mail Messages	54
Reading Received C-mail Messages	54
Using Emergency Rapid Mail	55
Receiving Emergency Rapid Mail	56

Camera 57

Photo Taking Tips	57
About Photo Modes	57
Taking a Photo	58
Viewing Photos	58

EZweb 59

Accessing Sites	60
Bookmarking Frequently Accessed Pages	61

Viewing Bookmarked Pages	61
Checking Charges	62
Downloading Chaku-Uta®	62

EZ News Flash 63

Basic Operations	63
Setting EZ News Flash	63

EZ Navi 65

Passenger Seat Navi for People in the Passenger Seat to Check the Route	65
Security Navi to Check Where Your Kids Are	65
EZ Navi Walk for When You Go Out	66
Evacuate Navi to Guide You Home or to Nearby Evacuation Areas during Disasters	67

TV (1Seg) 68

Initial Setup of TV (1Seg)	69
Watching TV (1Seg)	69
Exiting TV (1Seg)	70

In Case of Loss of Your GRATINA 71

Setting Conditions for Activating the Remote Ctrl Lock ..	71
Remotely Activating the Remote Ctrl Lock on Your GRATINA	71
Activating the Remote Ctrl Lock by the Security Lock Service	72



Troubleshooting 73**Index 75**

Getting Ready


Checking the Contents of the Box

The box contains the cell phone and accessories.

- Cell phone
- Battery pack
- Instruction Manual (Japanese)
- Warranty (Japanese)




- Desktop holder (KYY06PUA)




- An AC adapter and microSD memory card are not included. Purchase a specified AC adapter (sold separately) and a commercially available microSD memory card.

Names of Parts


From the Front



From the Back



From the Sides




Smart Sonic Receiver

Your product is equipped with a "smart sonic receiver" that transmits sound by the display vibrating. So while the receiver does not have holes for sound, you use it in a usual manner. Hold the product firmly against your ear as shown during a call, use Collect Sound, etc.

■ Holding the Receiver to Your Ear

Hold the product's receiver area against your ear as shown, so that it covers your ear and blocks surrounding sound to make calls more audible. Adjust the position of the cell phone up or down, left or right to suit your set sound quality and surroundings.




- Do not cover the product's microphone with your cheek or fingers during a call.
- If an earphone (sold separately) is connected, sound switches from the smart sonic receiver to earphone sound.
- Do not place stickers or sheets over the display. May affect receiver sound.
- Audibility varies with each person.
- Audibility differs depending on surroundings.

Charging the Battery Pack

The battery pack is not fully charged at the time of purchase. Be sure to charge the battery pack before using the cell phone for the first time.

- An AC adapter is not included. Purchase a specified AC adapter (sold separately).



- Be sure to close the cover of the external connection jack when charging is finished.
- Do not pull or twist the cover of the external connection jack forcibly.
- Be sure to use the common AC adapter 04 (sold separately) when charging overseas.

➔ Connect a specified AC adapter to the cell phone with the battery pack attached.

- Open the cover of the external connection jack. Check the shape of the connector of the AC adapter, and plug it straight into the external connection jack.

➔ Unfold the power plug of the AC adapter and plug it into an AC power outlet.

➔ Confirm that the charge indicator lights.

- Charging: The Information/Charge indicator lights.
- Charging finished: The Information/Charge indicator goes out.

Learning the Basics

Key Assignments




Diagram illustrating the key assignments for the mobile phone keypad:

- : Display Incoming History.
- : Display Calendar*.
- : Use Phone Book.
- : Display E-mail/C-mail menu.
- : Set/cancel Answer memo*. Delete characters. Cancel operation.
- : Make/answer calls.
- : Display the ticker field/info pane. Activate Camera*.
- : Display Outgoing History.
- : Display Main menu.
- : Display Apps menu.
- : Display EZ menu.
- : Turn power on*. End call/communication. Cancel operation.
- : Input phone numbers and characters.

Side Key Assignments






Diagram illustrating the side key assignment:

- : Set/cancel manner mode*.

* Hold down for at least one second.

- If you lose track of where you are or if you make a mistake, press to return to the previous screen. Press and return to the standby screen.

Hiding/Redisplaying the Message Menu


When the message menu is displayed on the standby screen, you can temporarily hide it by pressing  and then display the Main menu by pressing . To redisplay the hidden message menu, press  when the standby screen is displayed.

Message Menu




Turning On Power

Hold down  for at least one second.

- You cannot receive or make calls if  (out of range indicator) is displayed.











Turning Off Power

When the standby screen is displayed, hold down  for at least two seconds.

Switching the Display Language to English

You can switch the display language for function names and other items to English.

When the standby screen is displayed, press .

- ➔ Use  to select **機能設定** (Set Function) and then press  (選択 [Select]).
- ➔ Use  to select **画面表示** (Screen Display) and then press  (選択 [Select]).
- ➔ Use  to select **Set Language** and then press  (選択 [Select]).
- ➔ Use  to select **English** and then press  (OK).
- ➔ Use  to select **Alphabet** and then press  (OK).

Initial Setup of E-mail and EZweb

To use e-mail and EZweb, you need to apply for an EZweb subscription. If you did not apply for an EZweb subscription at the time of purchase, contact an au shop or the Customer Service Center.

Also, before use, you need to configure initial settings. Your e-mail address is assigned automatically in the initial setup.



When the standby screen is displayed, press .

➡ **Press  (OK).**



After a short while, your e-mail address is displayed.

➡ **Press  (OK).**

The initial settings are complete.

- You can also configure initial settings by pressing  or .


Checking Your Phone Number and E-mail Address

When the standby screen is displayed, press  and then .

Display Indicators

Display indicators inform you of mail arrival, current settings, etc.


Display




Indicator	Description	Indicator	Description
①	Battery level	⑦	New or unread E-mail/C-mail
②	Signal strength (reception field intensity)	⑧	— Current date and time
③	TV (1Seg) activated	⑨	Manner mode set
④	During a call	⑩	Auto Lock activated
	Missed calls	⑪	Answer memo set
⑤	EZapps activated	⑫	— Ticker field
	Connecting to EZweb	⑬	— Info pane
⑥	A microSD memory card (commercially available) inserted		








- The date and time are set automatically.

Sub-display

When the main unit is closed, the Sub-display shows the time or various notifications. To turn on the Sub-display, press .

You can switch the type of information shown on the Sub-display by pressing  each time.








Indicator		Description
①		Battery level
②		Signal strength (reception field intensity)
③		Manner mode set
④		Alarm set
⑤		Answer memo set
⑥		FeliCa status
⑦		Bluetooth® connection

Using Menu


You can access various functions from the Menu. The Menu patterns vary by model color. The operations and the screenshots for the Orange models are used in this manual.

Model Color	Menu Pattern
Orange/Pink/Yellow Green	Color panel
White	Crystal
Black	Digital

Color Piece	Color panel	Crystal	Digital	Simple Menu
				
Infrared Comm.				Infrared Comm.
Camera				Camera
microSD				microSD
TV				Notepad
Data Folder				Data Folder
Tools				Tools
Notepad				Calculator
Calculator				Set Functions
Clock/Calendar				Clock/Calendar
EZ FeliCa				-
Set Functions				-
Bluetooth				-

Changing Your E-mail Address

You can change the account name of your e-mail address.





When the standby screen is displayed, press .

➔ Use  to select *E-Mail Setup* and then press  (Select).

➔ Use  to select *Change Adr/Other* and then press  (Select).



The cell phone connects to the server.




➔ Use  to select *Eメールアドレスの変更* (Change E-mail Address) and then press  (Select).

➔ Use  to select the entry box, press  (Edit), enter your security code, and then press  (OK).


- Your security code is the four-digit number you wrote on your subscription form.
- If the security code is incorrectly entered three times consecutively during a single day, the e-mail address change operation will be disabled until the next day.

➔ Use  to select *送信* (Send) and then press  (Select).


➔ Use  to select *承諾する* (Accept) and then press  (Select).

➔ Use  to select the entry box, press  (Edit), enter an e-mail address using single-byte alphanumeric characters, and then press  (OK).

- For details on entering e-mail addresses, see page 47.

➔ Use  to select *送信* (Send) and then press  (Select).

➔ Use  to select *OK*, press  (Select) and then  (OK).

- Check that the e-mail address has been updated before pressing  (OK).

- Your e-mail address cannot be changed if the new address you enter in the above procedure is already being used. In this case, enter a different e-mail address.

Security Code and Passwords

You can use a security code and other passwords described below.

Take care not to forget your security code and passwords, because they are required for performing various operations and using subscription services.

Security Code

Usage Example	①Using the Answering Service (Voice Mail) and Call Transfer remotely from a fixed-line phone ②Making inquiries, applications, and changes while using Customer Service Center voice guidance, au web pages, and EZweb ③Changing the settings of <i>Spam Filter</i> or <i>Change Adr/Other</i> under E-mail Setup
Initial Setting	The four-digit number you wrote on your subscription form

Lock No.



Usage Example	Changing various settings of the cell phone
Initial Setting	1234

au Collective Payment Service/EZ Fee-Based Contents Service Password

Usage Example	①Subscribing or canceling subscriptions to EZweb fee-based contents paid by まとめてau 支払い (au Collective Payment Service) ②Purchasing products from EZweb sites using まとめてau 支払い (au Collective Payment Service) ③Subscribing or canceling subscriptions to EZ Fee-Based Contents Service
Initial Setting	The four-digit number you wrote on your subscription form

Making and Answering Calls

Making a Call

When the standby screen is displayed, use  to  to enter a phone number.



- When calling to a fixed-line phone, you also need to enter the area code.

➔ Press .

- To end the call, press .

- After you enter a phone number, you can add 184 or 186 to the phone number as follows:

➔ Press  (Call).

➔ Use  to select *Call 184* or *Call 186* and then press  (Call).

184: When you do not want to inform the other party of your phone number.


186: When you want to inform the other party of your phone number.


Making an International Call

au International Call Service

Available without any additional application

Example: To call 212-123-△△△△ in the USA

Enter the international access code, a country code, area code and phone number, and then press .



- International call charges are billed together with monthly local call charges.
- For more information on au International Call Service, dial either of the following numbers:
From au cell phones (toll-free):
157 (area code not required)
From fixed-line phones (toll-free):
0077-7-111
(Open 9:00 to 20:00 everyday)

Answering a Call

To answer a call, press .

- To end the call, press .

Display When a Call is Received

The phone number of the caller appears.



If the caller's phone number and name are in the phone book, the name is also displayed.

When the phone number of the caller is not displayed, one of the following indicators may appear.

Indicator	Meaning
<i>ID Unsent</i>	The caller did not send a Caller ID.
<i>Payphone</i>	The call is from a pay phone.
<i>Not Support</i>	The call is from a phone that does not support Caller ID.

Missed Call Notification


If you did not answer a call,  and *MissedCall* are displayed to let you know that you missed a call.

To check the caller's phone number, use  to select *MissedCall* and then press  (Check). You can then return the call (see the procedure on the right).

Returning a Call (Outgoing History/Incoming History)

Example: Returning a call to a phone number in the incoming history

When the standby screen is displayed, press .

- Press  while the standby screen is displayed to display the Outgoing History screen.

➔ Use  to select the phone number you want to call and then press  (Detail).

- Press  to display the Outgoing History screen.

➔ Press .

- The cell phone can store up to 50 phone numbers in each of the incoming and outgoing history.

One-ring Calls

What is a One-ring Call?



A one-ring call is a call from an unknown caller that only rings once, causing it to be stored in the incoming history. One-ring calls are often used to get you to return the call, which will connect you to a dating service or some other service that charges you at high rates.

One-ring Indicator

⚠ (red) indicator on the Incoming History screen indicates you have received a one-ring call (a call rang for three seconds or shorter). Be careful when you return a call to an unknown caller.





Adjusting the Earpiece Volume during a Call

During a call, use .

- : Increases the volume.
- : Decreases the volume.





Turning On Manner Mode

When the standby screen is displayed, hold down  for at least one second.

This turns on manner mode, and displays ,  and  on the standby screen. This also turns on Answer memo, which is indicated by  on the standby screen.

Turning Off Manner Mode

When the standby screen is displayed, hold down  for at least one second.

Turning off manner mode causes ,  and  to disappear from the standby screen. Answer memo is also turned off, which is indicated by  disappearing from the standby screen.



- Even in manner mode, the cell phone still emits a sound when autofocusing, a shutter sound when you take a photo.


Changing the Incoming Ring Tone

When the standby screen is displayed, press .

➔ Use  to select *Set Functions* and then press  (Select).

➔ Use  to select *Tone/Vib/Lamp* and then press  (Select).

➔ Use  to select *Incoming Setup* and then press  (Select).

➔ Use  to select *Incoming Call* and then press  (Select).


➔ Use  to select *Melody* and then press  (Select).

➔ Use  to select *Fixed RingTone* and then press  (Select).

➔ Use  to select *Preset Data* and then press  (Select).














➔ Use  to select a ring tone and then press  (OK).

The incoming ring tone is set.

- If you press  (Play), the tone plays.

Adjusting the Incoming Ring Tone Volume


When the standby screen is displayed, press .

- ➔ Use  to select *Set Functions* and then press  (Select).
- ➔ Use  to select *Tone/Vib/Lamp* and then press  (Select).
- ➔ Use  to select *Incoming Setup* and then press  (Select).
- ➔ Use  to select *Incoming Call* and then press  (Select).
- ➔ Use  to select *Volume* and then press  (Select).
- ➔ Use  to adjust the volume and then press  (OK).
 - Each press of  changes the volume one step.

STEP UP	The ring tone volume gradually increases.
5 (<i>Deka</i>) (Loud) }	The ring tone sounds at the set volume.
1 (soft)	
OFF	The ring tone does not sound.


Turning On the Answer Memo

When the standby screen is displayed, hold down  for at least one second.

 is displayed on the standby screen.

Turning Off the Answer Memo








When the standby screen is displayed, hold down  for at least one second.

The answer memo is turned off and  disappears from the standby screen.

- The cell phone can record a maximum of ten messages, each up to 60 seconds long.
- Answer memo is a function that automatically answers calls and allows callers to record messages. Use the Answering Service (Voice Mail) when your phone is turned off or when you are in a location where a signal cannot be received.













■ Playing a Message

If a message is recorded, *AnswerMemo* appears on the standby screen.

- ➔ Use  to select *AnswerMemo* and then press  (Check).
- ➔ Use  to select *Play Memo* and then press  (Select).
- ➔ Use  to select the message you want to play and then press  (Play).
 - To stop playing the message, press  (Stop).

■ Deleting a Message

When the standby screen is displayed, press .

- ➔ Use  to select *Answer Memo* and then press  (Select).
- ➔ Use  to select *Play Memo* and then press  (Select).
- ➔ Use  to select the message you want to delete and then press  (Menu).
- ➔ Use  to select *Delete* and then press  (Select).
- ➔ Use  to select *Delete One* and then press  (Select).
- ➔ Use  to select *YES* and then press  (OK).

Global Function

The product supports Global Passport CDMA service. You can use your product overseas without any additional application.

Setting the Area

When the standby screen is displayed, press .



➔ Use  to select *Tools* and then press  (Select).

➔ Use  to select *Global Function* and then press  (Select).

Precautions are displayed.

➔ Check the precautions and then press  (OK).

➔ Use  to select *Area Setting* and then press  (Select).

➔ Use  to select *Overseas (Auto)* and then press  (Select).

➔ Use  to select *YES* and then press  (OK).

- Some functions are not available when *Area Setting* is not set to *Japan*.

Obtaining the Latest PRL (Preferred Roaming List)

Manually update and set the PRL (preferred roaming list) before traveling abroad.

When the standby screen is displayed, press .

➔ Use  to select *Tools* and then press  (Select).

➔ Use  to select *Global Function* and then press  (Select).



Precautions are displayed.

➔ Check the precautions and then press  (OK).

➔ Use  to select *PRL Setting* and then press  (Select).

➔ Use  to select *PRL Manual Update* and then press  (Select).

➔ Use  to select *OK* and then press  (OK).
The cell phone connects to the server.

➔ Use  to select *PRLダウンロード* (Download PRL) and then press  (*ダウンロード* [Download]).



➔ Use  to select *最新ファイルはこちら* (The Latest PRL) and then press  (Select).

➔ Press  (OK).

The latest PRL is downloaded.

- The PRL (preferred roaming list) is the area information of overseas carriers offering international roaming service in partnership with KDDI (au).
- To obtain (download) the PRL, you need to subscribe to EZweb and make initial settings (see page 33) while in Japan.

Calling Japan from Overseas

When the standby screen is displayed, use  to  to enter a phone number.

➔ Press  (Call).


➔ Use  to select *Call to Japan* and then press  (OK).

➔ Press  (Call).

- You can use the product in CDMA network depending on what country or region you visit.

Character Input

Character Entry Modes

When a character entry screen is displayed, you can select a character entry mode if you press  (ChrTyp).

Menu Items

漢あ: Kanji/hiragana mode

カナ: Double-byte katakana mode


カ: Single-byte katakana mode

Aa: Double-byte alphanumeric mode

Aa: Single-byte alphanumeric mode

12: Double-byte number mode

12: Single-byte number mode

Use  to select a character entry mode and then press













 (Select).


Entering Alphanumeric Characters

You can use the keys  to  to enter characters.


More than one character is assigned to each key.

The following table shows the key assignment for entering characters.


Key	Number of Times to Press the Key								
	1	2	3	4	5	6	7	8	9
	.	@	—	_	/	:	~	1	
	a	b	c	A	B	C	2		
	d	e	f	D	E	F	3		
	g	h	i	G	H	I	4		
	j	k	l	J	K	L	5		
	m	n	o	M	N	O	6		
	p	q	r	s	P	Q	R	S	7
	t	u	v	T	U	V	8		
	w	x	y	z	W	X	Y	Z	9
	Inputs symbols								0
	Inputs symbols (switches an unconfirmed character between uppercase and lowercase).								
	Adds a line break and displays characters in the opposite order.								



When you change your e-mail address, you cannot use the characters in  for the account name (part of the address to the left of @).

■ Entering Two or More Characters Assigned to the Same Key

After you enter the first character, press  and then enter the next character.

■ Deleting Characters

To delete one character at a time, move the cursor to the character you want to delete and then press .

To delete all characters to the right of the cursor, hold down  for at least one second. If there are no characters to the right of the cursor, holding down  will delete all the characters.

■ Starting a New Line

Press .

Entering E-mail Addresses










■ E-mail Address Compatible Characters

- Before you enter an e-mail address, switch to the single-byte alphanumeric mode.
- When changing your e-mail address, you can enter up to 30 single-byte alphanumeric and symbol characters for the account name (part to the left of @). Note the following:
 - Uppercase characters cannot be used.
 - Period (.) cannot be used continuously, and cannot be used as the first or last character.
 - Zero (0) cannot be used as the first character.

■ How to Enter E-mail Addresses

Example: Entering "taro.23@kddi.co.jp"






Enter "taro.23".










- t : Press  once.
- a : Press  once.
- r : Press  three times.
- o : Press  three times.
- . : Press  once.
- 2 : Press  once and then .
- 3 : Press  once and then .

➡ Enter "@".

- @ : Press  twice.










➡ Enter "kddi".

- k : Press  twice.
- d : Press  once and then .
- d : Press  once.
- i : Press  three times.

- ➔ Press  (Menu).
- ➔ Use  to select *Get* and then press  (Select).
- ➔ Use  to select *UsefulSentence* and then press  (Select).
- ➔ Use  to select *Internet* and then press  (Select).
- ➔ Use  to select *.co.jp* and then press  (OK).
".co.jp" is entered.

Entering Pictograms




















When a character entry screen is displayed, press

-  (ChrTyp).
- ➔ Use  to select   and then press  (Select).
- ➔ Use  to select the pictogram you want to enter and then press  (OK).
 - You can enter pictograms consecutively if you press  (Continue) instead of  (OK).

Phone Book

Saving a Phone Book Entry







When the standby screen is displayed, hold down  for at least one second.

- ➔ Use  to select  [*Name*] and then press  (Edit).
- ➔ Enter a name and then press  (OK).
The  [*Reading*] for the name is entered automatically.
- ➔ Use  to select  [*Phone No.1*] and then press  (Edit).
- ➔ Enter a phone number and then press  (OK).
 - If the phone number is for a fixed-line phone, enter the phone number starting with the area code.
- ➔ Use  to select a phone number type and then press  (Select).
 - Follow the next step to enter an e-mail address. If you do not want to enter an e-mail address, press  (Comp).
- ➔ Use  to select  [*E-Mail Address1*] and then press  (Edit).
- ➔ Enter an e-mail address and then press  (OK).
- ➔ Use  to select an e-mail address type and then press  (OK).
- ➔ Press  (Comp).

- The phone book can store up to 1,000 entries.
- The cell phone automatically saves an entry to the lowest available memory number from 000 to 999.
- You can save three phone numbers and three e-mail addresses for each phone book entry.
- You can also assign a group No., and enter birthday, address, and other information.






Dialing from the Phone Book

When the standby screen is displayed, press .

- ➔ Use  to select the entry containing the phone number you want to dial and then press  (Detail).
- ➔ Use  to select the phone number and then press  (Select).
- ➔ Use  to select *Call* and then press  (Call).



Editing Phone Book Entries

When the standby screen is displayed, press .

- ➔ Select an entry and press  (Detail).
- ➔ Press  (Edit).
- ➔ Edit the contents and then press  (Comp).
- ➔ Use  to select *YES* and then press  (OK).

Saving a Phone Number from the Incoming or Outgoing History

Example: Saving a phone number from the incoming history to the phone book

When the standby screen is displayed, press  and use  to select the phone number you want to save.

➔ Press  (Menu).

➔ Use  to select *Add to Adr Bk* and then press  (Select).

➔ Use  to select *New* and then press  (Select).

➔ Use  to select a phone number type and then press  (OK).

- For details on saving a phone book entry, see page 49.

Using E-mail


















To use e-mail, you need to apply for an EZweb subscription. If you did not apply for an EZweb subscription at the time of purchase, contact an au shop or the Customer Service Center. Also, before use, you need to configure initial settings.

You can send and receive e-mail with other cell phones that support e-mail, and with PCs. In addition to text messages of up to 10,000 single-byte (or 5,000 double-byte) characters, you can also send photos and movies by e-mail.

- The packet communication charge for sending and receiving e-mail applies to the amount of data sent and received.
- You can send an e-mail message to up to 30 different addresses at one time.
- You can send up to 1,000 e-mail messages per day (a message with multiple recipients is counted as more than one message).
- Sending and receiving e-mail messages that include attachment data may take a while.

Creating and Sending E-mail Messages

When the standby screen is displayed, press .



- ➔ Use  to select *Create New E-Mail* and then press  (Select).
- ➔ Use  to select *Destination* and then press  (Edit).
- ➔ Use  to select *Get Adr Bk (1)* and then press  (Select).
- ➔ Use  to select a phone book entry and then press  (OK).
- ➔ Use  to select an address and then press  (OK).
- ➔ Use  to select *Subject* and then press  (Edit).
- ➔ Enter a subject and then press  (OK).
 - You cannot enter single-byte katakana characters or a new line in a subject.
- ➔ Use  to select *Body* and then press  (Edit).
- ➔ Enter text and then press  (OK).
 - You cannot enter single-byte katakana characters.
- ➔ Press  (Send).

Reading Received E-mail Messages

When you receive an e-mail message, *New E-Mail* appears on the standby screen.




➔ Use  to select *New E-Mail* and then press  (Check).

➔ Press  (Select).

- : Indicates a read message.
- : Indicates an unread message.

➔ Use  to select the new message and then press  (View).

Reading an E-mail Message from the E-mail Menu



When the standby screen is displayed, press  to display the E-mail menu, use  to select *Inbox* and then press  (Select).



For subsequent operations, see "Reading Received E-mail Messages" above.

Reading an E-mail Message with an Attached Photo or Movie


Example: Viewing an attached photo

Display the e-mail message that has an attached photo (above).

➔ Use  to select the file name and then press  (Select).

➔ Use  to select the file name and then press  (Receive).

➔ Press  (Play).

- Selecting the file name or pressing  (Receive) may be unnecessary for some files to be displayed, depending on the file size.

Replying to Received E-mail Messages

When the standby screen is displayed, press .

➔ Use  to select *Inbox* and then press  (Select).

➔ Press  (Select).

➔ Use  to select the message you want to reply to and then press  (View).

➔ Press  (Reply).

"Re:" is prefixed to the subject, and the text of the message is quoted.

➔ Refer to "Creating and Sending E-mail Messages" (page 51) for subsequent operations.

Rejecting Spam

Setting mail filters to reject spam is recommended.
The recommended settings help you to set mail filters easily.

Recommended Settings

Mail filter is set to reject spoofing mail, auto-forwarding mail and to receive mail sent from a cell phone, PHS, or PC.

When the standby screen is displayed, press .

➡ Use  to select *Spam Filter* and then press  (Select).

➡ Use  to select **オススメの設定へ (To Recommended Settings)** and then press  (Select).

➡ Use  to select **登録 (Registration)** and then press  (Select).

- You can also prevent spam by changing your e-mail address. For details on changing your e-mail address, see page 37.

Using C-mail

C-mail is a service that uses phone numbers as addresses to exchange messages between cell phones. A C-mail message can contain up to 140 single-byte (or 70 double-byte) characters.

- The C-mail send charge applies when sending C-mail.








C-mail Safety Block










C-mail safety block is a function that allows you to reject C-mails that include URLs (<http://△△△>, <https://△△△>) or phone numbers in the C-mail message text.

C-mail safety block is valid by default. Cancel the setting if you want to receive C-mails that include URLs and phone numbers in the message text.

Creating and Sending C-mail Messages







When the standby screen is displayed, hold down  for at least one second.

- ➔ Use  to select *Create New C-Mail* and then press  (Select).
- ➔ Use  to select  [*Destination*] and then press  (Edit).
- ➔ Use  to select *Get AddressBook* and then press  (Select).




- ➔ Use  to select a phone book entry and then press  (OK).
- ➔ Use  to select a phone number and then press  (OK).
- ➔ Use  to select  [*Body*] and then press  (Edit).
- ➔ Enter text and then press  (OK).
- ➔ Press  (Send).

Reading Received C-mail Messages

When you receive a C-mail message, *New C-Mail* appears on the standby screen.

- ➔ Use  to select *New C-Mail* and then press  (Check).
 - : Indicates a read message.
 - : Indicates an unread message.
- ➔ Use  to select the new message and then press  (View).

Reading a C-mail Message from the C-mail Menu

When the standby screen is displayed, hold down  for at least one second to display the C-mail menu, use  to select *Inbox* and then press  (Select). For subsequent operations, see "Reading Received C-mail Messages" above.

Using Emergency Rapid Mail

Emergency Rapid Mail is a service that distributes Earthquake Early Warning or Tsunami Warning delivered from the meteorological bureau or Disaster and Evacuation Information delivered from the government or local public organization to all au cell phones in specified areas simultaneously.

When you purchase the product, "Receive Setup" of the Emergency Rapid Mail is set to "Receive". Reception setting of Tsunami Warning is available in the settings of Disaster and Evacuation Information.

When you receive Earthquake Early Warning, ensure your safety and take proper action according to the situation around you. When you receive a Tsunami Warning, draw away from sea coast immediately and evacuate to safe place such as upland or well-built high building.

- Reception of Emergency Rapid Mail is notified by a special warning tone and vibration. It is not possible to change the warning tone.

* An Early Earthquake Warning is notified by a warning tone, announcement ("Jishin desu" (Earthquake)) and vibration.

- Earthquake Early Warning is sent to areas where strong quakes (over 4 degrees) are expected when the earthquake whose the maximum seismic intensity 5 lower is anticipated occurs.

- Immediately after an earthquake occurs, quakes (P waves and initial tremors) near the epicenter are detected and position, scale, and expected strength are automatically calculated and notification is sent as soon as possible within a few seconds to tens of seconds before the strong quakes (S waves and major tremors) caused by the earthquake start.
- Earthquake Early Warning may not arrive before strong tremors in arrears near the epicenter.
- Tsunami Warning is a notification delivered from the meteorological bureau (major tidal wave, seismic sea wave) to the area including target coast.
- Disaster and Evacuation Information is a service that distributes bulletins concerning residents' safety including evacuation advisories, evacuation orders and other warnings issued by the national and local governments.
- The service is available only in Japan (it cannot be used overseas).
- No information fee or communication charge is required for receiving Emergency Rapid Mail.
- KDDI is not liable for damages suffered by customers resulting from the service's information, lack or delay in the information caused by transmission or system breakdowns, or other events that are outside the responsibility of KDDI.
- Refer to the Japan Meteorological Agency web page for details about distribution of Earthquake Early Warning.
<http://www.jma.go.jp/> (from PC)





Receiving Emergency Rapid Mail

Reception of emergency rapid mail is notified by a special warning tone, vibration and screen display.

When an Earthquake Early Warning is received, a warning tone (cannot be changed) sounds and Earthquake or Disaster is displayed.

➡ Use ☐ to select *Earthquake or Disaster* and then press ☐ (Check).


- You cannot receive Emergency Rapid Mail during a call. You also might not be able to receive Emergency Rapid Mail during C-mail/E-mail and EZweb transmissions.
- You might not be able to receive Emergency Rapid Mail when your cell phone is turned off or if you are in a place where signal does not reach even in the service area (e.g. in a tunnel, basement) or in a place with a poor reception. In such instances, Emergency Rapid Mail cannot be received again.
- This delivery system is different from Early Warning provided through TV, radio, or other communication procedures, which means that the time the Early Warning arrives may vary.
- Information from someplace other than your current location may be received.
- It is not possible to change the warning tone or adjust the volume of Emergency Rapid Mail.
- While using EZweb, EZ appli or TV (1Seg), the warning tone might not sound, with only screen display and vibration to notify you.

- If Emergency Rapid Mail arrives while you are operating your cell phone,  appears, the warning tone sounds, and your cell phone vibrates to notify you. End the operation and return to standby to view the icon for the received Emergency Rapid Mail.
-  is displayed for unread Emergency Rapid Mail.
* For received C-mail/E-mail,  is displayed instead of .
- The warning tone for Emergency Rapid Mail sounds at a fixed volume even if [Volume] in [C-Mail Receive (M214)] is set to [OFF].
- Your cell phone vibrates with the warning tone even if [Vibrator] in [C-Mail Receive (M214)] is set to [OFF].
- Open your cell phone if information appears in the subdisplay to view the received Emergency Rapid Mail.


Camera

Your cell phone has a CMOS camera with 8.08 effective megapixels for shooting photos and movies. You can use the self-timer and autofocus. Shot images can be used for the standby screen, and attached to e-mail messages.

Photo Taking Tips

When taking photos, position the cell phone so that  is not displayed upside down or inclined. Frame the subject within the display and hold the cell phone steady with both hands to avoid shaking.

Portrait Position




About Photo Modes

The following modes are available for taking photos.


Mode	Photo Size	Storage Location
Wallpaper	Wallpaper	The <i>Photo Folder</i> in the Data Folder of the cell phone
	Wallpaper (Wide)	
Camera	0.3M	
	1M	
	2M	
	3M	
	8M	

- Take care not to cover the lens with a strap or finger.

Taking a Photo


When the standby screen is displayed, hold down  for at least one second.


The monitor screen appears.

➡ **Point the monitor screen at the subject and then press  (Shoot).**

The camera focuses automatically and the shutter clicks.
The preview screen is displayed.

Saving a Photo

Press  (Save) on the preview screen.


- If you do not want to save the photo, press  on the preview screen.

Viewing Photos

When the standby screen is displayed, press .

➡ Use  to select *Data Folder* and then press  (Select).

➡ Use  to select *Photo Folder* and then press  (Select).

➡ Use  to select a folder and then press  (Select).

➡ Use  to select the photo you want to view and then press  (Play).

EZweb is an information service that allows you to enjoy browsing the Internet on your cell phone. You can also download Chaku-Uta®, news, and other contents from web pages.

To use EZweb, you need to apply for an EZweb subscription. If you did not apply for an EZweb subscription at the time of purchase, contact an au shop or the Customer Service Center. Also, before use, you need to configure initial settings.

- The packet communication charge for EZweb connection applies to the amount of data sent and received, not to the length of time connected.
- In addition to communication charges, some sites charge for providing information.

Accessing Sites

■ Viewing the au Portal

You can access EZweb from the au Portal. A variety of useful and fun sites are available on EZweb.

When the standby screen is displayed, press , use  to select *Top Menu/Search* and then press  (Select).



auお客さまサポート (au Customer Support)
Provides information about charges, various applications, au online manual and notices from au.

メニューリスト (Menu List)
Provides a list of various content provider sites.

キーワード検索機能 (Search by Keyword)
Provides a search function for searching for information by keyword.

主要ニュース・エンタメニュース・天気／占い (Top News, Entertainment News, Weather & Horoscope)
Provides direct access to the au Portal services.

最新オススメ情報 (Latest News)
Introduces up-to-date information concerning entertainment, daily life, etc.

知る (Tips & Tools)
Provides information on sports and stock prices, as well as useful tools such as maps and dictionaries.

楽しむ (Hobbies & Culture)
Provides the latest information, such as games, music, books, hobbies and entertainment.

買う (Shopping & Auctions)
Provides a list of shopping and auction sites available from your cell phone.

暮らす (Lifestyle)
Provides travel, restaurant and other lifestyle-oriented information.



使える (Community & Communication)
Provides interesting and useful services such as SNS, Emoji.



オープンサイト (Open Site)
Introduces open sites.

au style
Introduces information and sites that au recommends.








災害用伝言板 (Disaster Message Board)
Register and confirm safety information in time of disaster.

Basic Operations

Use  to select the site you want to access and then press  (Select).



Press  to return to the previous screen. Hold down  for at least one second to return to the au Portal.

The following describes the basic operations that are available while accessing sites.

Key Operation	Description
	Exits EZweb.
	Moves the cursor up and down. When there is data available above or below the current screen, scrolls up and down the screen one line at a time.
 / 	When there is data available above or below the current screen, scrolls the screen page by page.  : Scrolls one page up.  : Scrolls one page down.
	Returns to the previous screen.

Bookmarking Frequently Accessed Pages

When the page you want to bookmark is displayed, press  (Brow. Menu).

➔ Use  to select *New bookmark* and then press  (Select).

- Some pages cannot be bookmarked.

➔ Press  (Store).



The displayed page is bookmarked, and its title and URL are added to the Bookmark.

- The Bookmark can contain up to 100 titles and URLs.

Viewing Bookmarked Pages








When the standby screen is displayed, press .

➔ Use  to select *Bookmark* and then press  (Select).

➔ Use  to select the bookmark for the page you want to view and then press  (Select).
The cell phone connects to the site.









Checking Charges

When the standby screen is displayed, press .

- ➔ Use  to select *Set Functions* and then press  (Select).
- ➔ Use  to select *Time/Toll/Subs* and then press  (Select).
- ➔ Use  to select *Inquiry Toll* and then press  (Connect).
- ➔ Press  (OK).
 - Select the item you want to check and then follow the on-screen instructions.

Downloading Chaku-Uta®


When the standby screen is displayed, press .

- ➔ Use  to select *Top Menu/Search* and then press  (Select).
- ➔ Use  to select *メニューリスト (Menu List)* and then press  (OK).
- ➔ Use  to select *着うた (Chaku-Uta®)* and then press  (Select).
- ➔ Use  to select the site you want to access and then press  (Select).

The download instructions appear.

 - Fee-based information sites require entry of au Collective Payment Service/EZ Fee-Based Contents Service password. Follow the on-screen instructions to enter the password. See page 38 for details.
- ➔ Follow the on-screen instructions.

Download is completed.

 - Downloaded data is saved automatically to the Data Folder.
- ➔ Press  (Play).


The downloaded Chaku-Uta® plays.


- This procedure is only an example for the purpose of explanation and may differ from actual procedures. Follow the instructions on the site from which you want to download the data.

Use the EZ News Flash to display flash news on the standby screen. You can check the news details and other information by selecting the ticker field.

You can use the EZ News Flash by making a few simple settings following the EZweb initial setup.

Basic Operations



- The EZ News Flash information is automatically received at no charge. Note, however, that packet communication charges may be incurred for manual updates and connecting to EZweb sites. In this case, a confirmation screen for network connection is displayed.
- The EZ News Flash information is updated at regular time intervals.  appears while receiving information.

Setting EZ News Flash

The EZ News Flash is available free of charge. You have only to make a few simple settings. After following the procedure in “Initial Setup of E-mail and EZweb” on page 33, configure EZ News Flash settings. If you did not configure the EZ News Flash settings at the time of the initial setup, follow the steps below.

When the standby screen is displayed, press and select the ticker field and then press (OK).



➔ Follow the on-screen instructions.

The setup procedure is completed.

- When the standby screen returns, a message asking you to wait for a while until the next update takes place appears in the ticker field.

■ Canceling EZ News Flash

When the standby screen is displayed, press  and select the ticker field and then press  (OK).

➡ Press  (メニュー[Menu]), use  to select サービス設定解除 (Service Cancellation) and then press  (選択[Select]).

➡ Follow the on-screen instructions.

■ Changing the Reception Settings for EZ News Flash Information

You can change the ring tone, vibrator and LED settings under M215 *NewsFlash Rcv* for reception of EZ News Flash information.

If you do not want the ring tone to sound when receiving EZ News Flash information, set the volume to *OFF*.

Using GPS (Global Positioning System), EZ Navi provides useful positional information services.

When the standby screen is displayed, press

 **and then use**  **to select the *EZnavi*.**

- The packet communication charges for using EZ Navi services apply to the amount of data sent and received. Some services may require a separate information fee.
- Before using EZ Navi, you must configure initial settings of EZweb (page 33).

Passenger Seat Navi for People in the Passenger Seat to Check the Route

Passenger Seat Navi guides the passengers to the destination with the best route using voice and map.

Drivers are not allowed to use Passenger Seat Navi.

Security Navi to Check Where Your Kids Are

The Security Navi application is made up of the following three functions:

いつでも位置確認 (Auto Position Search [monthly charge]),
エリア通知 (Area Message [no monthly charge]),
位置確認メール (Position Search Mail [no monthly charge])

Using these functions, you can check the position of an au cell phone that supports Security Navi; and automatically receive a notification from the specified au cell phones when your kids enter (or are in) or leave (or are no longer in) the set area within a predetermined period of time.

EZ Navi Walk for When You Go Out

Displays various useful menu items for when you are out. There are two menu modes: the Full Mode menu for those who want to use all the convenient functions including the latest features, and the Simple Mode menu with limited functions allowing you to use the service with simple operation.

The following table describes the Full Mode menu.

フリーワード検索 (Free Word Search)	Search by entering names of facilities and stores, or key words of stations and addresses.
トータルナビ／地図 (Total Navigation/Map)	Find the most preferable combination of transportation (trains, airplanes, buses and taxis), and check out maps of your current location and places you like to go.
乗換／時刻表 (Connection/Timetable)	Search for train connections, timetables and other public transportation information.
お店／施設／イベント (Shop/Facility/Event)	Search for local stores, facilities or events.
ドライブ／渋滞情報 (Road/Traffic Information)	Check out road traffic information in real time.
オススメ便利メニュー (Useful Menu)	View information on services that are available on PCs, and use advanced functions of EZ Navi Walk that you can enjoy.
設定／会員登録／インフォ (Setting/Membership Registration/Information)	Configure various settings, sign up as a member or check out various useful information.

- Some of the menu options require a monthly charge.

View Your Current Location



★ represents your initial location. As you start moving, changes of your location are tracked by continuous positioning and indicated in real time by 🧑.

The *現在地の地図* (The Map of Your Current Location) option displays the current map in real time.

3D Navi

Shows a 3D view at guidance points and around the destination area.

Evacuate Navi to Guide You Home or to Nearby Evacuation Areas during Disasters

Nearby public evacuation areas or the direction to your home can be determined using the map data pre-installed on the product (避難所マップ[Evacuate Area Map]). Other useful contents can be downloaded from the 災害時ナビ(Evacuate Navi) section of the EZweb site.

- Some contents require a monthly charge.
- Use the information on the screen as a reference and always follow the instructions of police, fire and other municipal authorities.
- When using Evacuate Navi, checking your current position may take more time than usual depending on the status of the GPS satellites.


TV (1Seg)

EZweb Subscription Required

"1Seg", a mobile terrestrial digital television service in Japan, is available on the product.

Using the Built-in TV Antenna

The whole body of the product functions as a TV antenna. When you watch TV (1Seg), avoid covering the product with your hand in order to ensure good reception.



- Before using TV, you must configure initial settings of EZweb (page 33).
- If you are watching TV indoors, you may be able to improve the reception by moving closer to a window.

- The continuous viewing times of TV (1Seg) are as follows. The figures vary according to the usage of data broadcasts.

Continuous viewing time	Approx. 4 hrs 50 min.
-------------------------	-----------------------

Times measured with volume at "10" and subtitles setting at "OFF". Continuous viewing time changes depending on operation, etc.

- For information about the "1Seg" service, refer to the following homepage.

The Association for Promotion of Digital Broadcasting



From a PC	http://www.dpa.or.jp/
From a cell phone	http://www.dpa.or.jp/1seg/k/

Initial Setup of TV (1Seg)

To watch TV (1Seg), you need to configure initial settings.

When the standby screen is displayed, press .

➔ Use  to select *TV* and then press  (Select).

➔ Use  to select *TV (1Seg)* and then press  (Select).

Disclaimer notes are displayed.

➔ Use  to check the disclaimer notes, use  to select *OK*, and then press  (選択 [Select]).

The initial setting screen for using TV (1Seg) is displayed.


- The screen for setting TV (1Seg) channels appears.

➔ Use  to select **放送波スキャン (Broadcast signal scan)** and then press  (選択 [Select]).



Automatic channel scanning begins. When receivable channels are found, the channel setup is completed.

- Select **マニュアル設定 (Manual)** to set the channel manually.

Watching TV (1Seg)


When the standby screen is displayed, press .

➔ Use  to select *TV* and then press  (Select).

➔ Use  to select *TV (1Seg)* and then press  (Select).

■ To Change Channels

Use  to change channels.



- Before using this feature, you must configure TV (1Seg) initial settings (see the procedure on the left).

Exiting TV (1Seg)

Press , use  to select *YES* and then press  (OK).
















In Case of Loss of Your GRATINA













The Remote Ctrl Lock allows you to remotely activate the Auto Lock, FeliCa Lock, and Address Book Lock, preventing others from using your cell phone.

Setting Conditions for Activating the Remote Ctrl Lock

You can activate the Remote Ctrl Lock by calling your product a set number of times from a registered phone number within a specified period of time.

When the standby screen is displayed, press .

- ➔ Use  to select *Set Functions* and then press  (Select).
- ➔ Use  to select *Priv/Restrict* and then press  (Select).
- ➔ Use  to select *Security Lock* and then press  (Select).
- ➔ Use  to select *Remote Lock* and then press  (Select).
- ➔ Enter Lock No., and then press  (OK).
- ➔ Use  to select *ON/OFF Setup* and then press  (Select).
- ➔ Use  to select *ON* and then press  (OK).
- ➔ Use  to select *Caller No.List* and then press  (Select).

- ➔ Use  to select *00* and then press  (Edit).
- ➔ Use  to select *Input Phone No.*, press  (Select), enter a phone number, and then press  (OK).
- ➔ Press  (Back).
- ➔ Use  to select *Set Time* and then press  (Select).
- ➔ Enter a time and then press  (OK).
 - This sets the time limit for receiving the set number of calls after the first call is received.
 - You can set a time from one to ten minutes.
- ➔ Use  to select *No. of Calls*, and then press  (Select).
- ➔ Enter a number of calls, and then press  (OK).
 - This sets the number of calls to receive to activate the Remote Ctrl Lock.
 - You can set a number of calls from five to ten.

Remotely Activating the Remote Ctrl Lock on Your GRATINA

Call the product from the registered phone number repeatedly within the set time limit.

- When the specified number of calls are received, the Remote Ctrl Lock is activated and a message plays telling you that the cell phone is locked.

Activating the Remote Ctrl Lock by the Security Lock Service


Even if the Remote Ctrl Lock is not set in advance, the Remote Ctrl Lock can be activated by calling Customer Service Center or completing the application process on au Customer Support from a PC.

The Security Lock Service is available free of charge.

■ Calling Customer Service Center for Activating/Canceling the Remote Ctrl Lock

From an au cell phone: 113 without a prefix (toll free)

From any other cell phone or fixed-line phone:

 0077-7-113 (toll free)

Open 24 hours

Follow the voice guidance to complete the application process.











■ Activating/Canceling the Remote Ctrl Lock from a PC






Login to au Customer Support (<https://cs.kddi.com/>) and complete the application process by following the on-screen instructions.


- You must fill out an application to use au Customer Support (the application can be filled out even after your cell phone is lost).

- The Remote Ctrl Lock cannot be activated when the product is turned off or out of the service area, or Emission OFF is set.

Troubleshooting

Symptom	Possible Cause	Remedy	Page
Cannot turn on power.	● Is the battery pack charged?	Charge the battery pack.	30
	● Did you hold down  for at least one second?	Hold down  for at least one second.	32
Cannot make calls.	● Is power turned on?	Hold down  for at least one second.	32
	● Is  (out of range indicator) displayed?	Move to a location where  (out of range indicator) is no longer displayed, and try again. Also check the <i>Area Setting</i> .	32, 44
	● Is your hand or a metal object covering the area around the built-in antenna?	Make sure your hand or any other metal object is not covering the area around the built-in antenna.	28
	● Did you enter the phone number starting with the area code?	When making a call to a phone other than a cell phone, you need to enter the area code even if you are inside the same area.	39
Cannot receive calls.	● Is  (out of range indicator) displayed?	Move to a location where  (out of range indicator) is no longer displayed. Also check the <i>Area Setting</i> .	32, 44
	● Is power turned on?	Hold down  for at least one second.	32
No response when a key is pressed.	● Is power turned on?	Hold down  for at least one second.	32
A warning tone sounds and power turns off.	● Is there enough power left in the battery pack?	Charge the battery pack.	30
Calls are answered automatically.	● Is Answer memo turned on?	Hold down  for at least one second to turn off Answer memo.	42

Symptom	Possible Cause	Remedy	Page
Cannot hear the other party.	● Is the earpiece volume too low?	Press  during a call to increase the earpiece volume.	41
	● Is the receiver held against your ear?	Hold the receiver against your ear.	29
When making a call, a beeping sound is heard from the earpiece and a connection cannot be established.	● Is  (out of range indicator) displayed? Or are you in a location where the signal is too weak?	Move to a location where  (out of range indicator) is no longer displayed. Also check the <i>Area Setting</i> .	32, 44
	● Is the wireless line busy or is the phone you are calling on another line?	End the call and try again later.	39
The incoming LED flashes but the ring tone does not play.	● Is manner mode turned on?	Hold down  for at least one second to turn off manner mode.	41
	● Is  (ring tone off indicator) displayed?	Increase the volume of the incoming call ring tone.	42
Cannot charge the battery pack.	● Is the battery pack installed properly?	Install the battery pack properly.	30
	● Are the plug and connector of the AC adapter inserted properly?	Insert the plug and connector firmly.	
When the camera is activated, no subject is displayed.	● Is a finger or other object covering the camera (lens)?	Check the position of the camera (lens) and remove the obstacle.	57

- For more details, contact the Customer Service Center.
From a land-line phone,  0077-7-111
From an au cell phone, 157 without area code

Index

Numeric

1Seg	68
------------	----

A

Accessories	27
Answer memo	42
Playback	43
Turning off	42
Turning on	42

B

Back cover	28
Battery level	34
Battery pack	27, 30

C

Camera	57
Photo taking tips	57
Taking a photo	58
Cell phone etiquette	23
Character input	46
Character entry modes	46
Deleting characters	47
Starting a new line	47
Charging the battery pack	30
Checking charges	62

C-mail	54
C-mail safety block	54
Creating and sending	54
Reading	54
Received mail	54
Contents	25

D

Disaster Message Board Service	24
Display	34
Domain	37
Downloading Chaku-Uta®	62

E

Earpiece volume	41
E-mail	51
Creating and sending	51
Initial settings	33
Reading	52
Received mail	52
Replying	52
Viewing attached images	52
E-mail address	33
Available characters	47
Changing	37
Entering	47
Emergency Rapid Mail	55
Entering pictograms	48
Evacuate Navi	67
EZ Navi	65

EZ Navi Walk	66
EZ News Flash	63
Canceling	64
Changing the Reception Settings	64
Info pane	63
Setting	63
Ticker field	63
EZweb	59
Accessing sites	60
au Portal	60
Basic operations	61
Initial settings	33

G

Global Function	44
Calling Japan from Overseas	45
Obtaining the Latest PRL (Preferred Roaming List)	44
Setting the Area	44

I

Incoming history	40
Indicators	34
Initial settings	33, 69
E-mail-EZweb	33
TV (1Seg)	69
International Call	39
Internet	59
Sites	60

K

Key assignments	31
-----------------------	----

L

Language	32
Learning the basics	31
Lock No.	38

M

Mail	51
C-mail	54
E-mail	51
Emergency Rapid Mail	55
Mail filters	53
Recommended settings	53
Manner mode	41
Menu	36
Message Menu	32

N

Names of parts	28
----------------------	----

O

One-ring calls	40
Outgoing history	40

P

Passenger Seat Navi	65
Passwords	38
Phone (call)	39
184/186	39
Answering	40
International Call	39
Making	39
Returning	40
Phone book	49
Dialing	49
Editing	49
Saving	49
Saving a phone number from the incoming or outgoing history	50
Phone number	33
Photos	57
Photo modes	57
Taking	58
Viewing	58
Playback	
Answer memo	43

R

Remote Ctrl Lock	71
Ring tones	
Changing the type	41
Changing the volume	42

S

Security code	38
Security Lock Service	72
Security Navi	65
Signal strength	34
Sites	60
Bookmarking	61
Viewing from bookmarks	61
Smart Sonic Receiver	29
Spam	53
Sub-display	35

T

Troubleshooting	73
Turning on/off power	32
TV (1Seg)	68
Built-in Antenna	68
Changing channels	69
Exiting	70
Initial settings	69

V

Viewing	
Photos	58

For inquiries, call:

Customer Service Center

For general information and charges (toll free)

From fixed-line phones:



0077-7-111

From au cell phones:

157

area code not required

PRESSING ZERO WILL CONNECT YOU TO AN OPERATOR
AFTER CALLING 157 ON YOUR au CELL PHONE

For line suspension (because of loss or theft)
and operation information (toll free)

From fixed-line phones:



0077-7-113

From au cell phones:

113

area code not required

In case above numbers are not available,



0120-977-033 (except Okinawa)



0120-977-699 (Okinawa)

Secure cell phone support center

For loss, theft, or damage (toll free)

From fixed-line phones/au cell phones:



0120-925-919

(Open 9:00 to 21:00 everyday)

From EZweb:

Access Method

EZ ▶ Top Menu/Search ▶ auお客さまサポート (au Customer Support)
▶ お問い合わせ (Inquiries)
* Menus are subject to change without prior notice.



モバイル・リサイクル・ネットワーク
携帯電話の資源を再利用するためのネットワーク

Cell phone and PHS operators collect and recycle unused telephones, batteries and battery chargers at stores bearing the  logo regardless of brand and manufacturer to protect the environment and reuse valuable resources.

Read this code for an easy
access to au Online Manual.
(Packet communication charges
do not apply.)

September 2013 1st Edition

Sales: KDDI CORPORATION •
OKINAWA CELLULAR TELEPHONE COMPANY
Manufactured by: KYOCERA Corporation

